


FX-200 series

Functional X-ellence Station



Class 3R Laser Product

HOW TO READ THIS MANUAL

Thank you for selecting the FX-200 series.

- Please read this Operator's manual carefully, before using this product.
- FX has a function to output data to a connected host computer. Command operations from a host computer can also be performed. For details, refer to "Communication manual" and ask your local dealer.
- The specifications and general appearance of the instrument are subject to change without prior notice and without obligation by TOPCON CORPORATION and may differ from those appearing in this manual.
- The content of this manual is subject to change without notice.
- · Some of the diagrams shown in this manual may be simplified for easier understanding.
- Always keep this manual in a convenient location and read it when necessary.
- This manual is protected by copyright and all rights are reserved by TOPCON CORPORATION.
- Except as permitted by Copyright law, this manual may not be copied, and no part of this manual may be reproduced in any form or by any means.
- This manual may not be modified, adapted or otherwise used for the production of derivative works.

Symbols

The following conventions are used in this manual.

: Indicates precautions and important items which should be read before operations.

: Indicates the chapter title to refer to for additional information.

Note : Indicates supplementary explanation.

: Indicates an explanation for a particular term or operation.

[MEAS] etc. : Indicates Operation icons on the display and window dialog buttons.

(ESC) etc. : Indicates keys on the operation panel.

<Screen title> etc.: Indicates screen titles.

Notes regarding manual style

- Except where stated, "FX" means FX-200 series in this manual.
- The FX-200 series is available in "standard", and "Low Temperature" models. Users with a "Low Temperature Model" should read the additional precautions specific to use under low temperatures.

●Low Temperature Model

Low Temperature Models display the seal shown at right.



Do not remove the Low Temperature Model seal from the instrument.
 This seal is used for model recognition by our engineers during maintenance.



- Screens and illustrations appearing in this manual are of FX-203 (with Bluetooth module and display on face 1 only). Face 2 display is available as standard or as a factory option depending on the country of purchase.
- Screens appearing in this manual are based on the setting "Dist. reso: 1 mm". When "Dist. reso: 0.1 mm" is selected, the number of decimal places for distance and atmospheric condition input values will be increased by one.

20.1 Observation Conditions

- Location of softkeys in screens used in procedures is based on the factory setting. It is possible to change the allocation of softkeys.
 - Softkey allocation: "20.6 Allocating Key Functions"
- Learn basic operations in "4. PRODUCT OUTLINE" and "5. BASIC OPERATION" before you read each measurement procedure. For selecting options and inputting figures, see "5.1 Basic Key Operation".
- Measurement procedures are based on continuous measurement. Some information about procedures when other measurement options are selected can be found in "Note" (Note).
- KODAK is a registered trademark of Eastman Kodak Company.
- Bluetooth® is a registered trademark of Bluetooth SIG, Inc.
- Windows is registered trademarks of Microsoft Corporation.
- All other company and product names featured in this manual are trademarks or registered trademarks of each respective organization.



SIMA This is the mark of the Japan Surveying Instruments Manufacturers Association.

CONTENTS

1.		
2.		
3.	LASER SAFETY INFORMATION	7
	4.1 Parts of the Instrument	g
	4.2 Mode Structure	12
	4.3 Bluetooth Wireless Technology	13
5.	BASIC OPERATION	
	5.1 Basic Key Operation	15
	5.2 Display Functions	
	5.3 Inputting Characters using the Input Panel	
	5.4 Starkey Mode	
6.		
	7.1 Battery Charging	
	7.2 Installing/Removing the Battery	
8.	SETTING UP THE INSTRUMENT	
•	8.1 Centering	
	8.2 Levelling	
9.	POWER ON/OFF	
•	9.1 Resolving Software Issues	
	9.2 Configuring the Touch Panel	
10.	CONNECTING TO EXTERNAL DEVICES	
. • .	10.1 Wireless Communication using <i>Bluetooth</i> Technology	
	10.2 Communication between the FX and Companion Device	
	10.3 Connecting to USB devices	
	10.4 Connection via RS232C cable	
11	. FOCUSSING AND TARGET SIGHTINGS	
	ANGLE MEASUREMENT	
	12.1 Measuring the Horizontal Angle between Two Points (Horizontal	
	12.2 Setting the Horizontal Angle to a Required Value (Horizontal Ang	
	12.3 Angle measurement and Outputting the Data	
13.	DISTANCE MEASUREMENT	
	13.1 Returned Signal Checking	
	13.2 Distance and Angle Measurement	
	13.3 Distance Measurement and Outputting the Data	
	13.4 REM Measurement	
14.	. COORDINATE MEASUREMENT	
	14.1 Entering Instrument Station Data	
	14.2 Azimuth Angle Setting	
	14.3 3-D Coordinate Measurement	
15.	RESECTION MEASUREMENT	
	15.1 Coordinate Resection Measurement	
	15.2 Height Resection Measurement	
16	SETTING-OUT MEASUREMENT	
	16.1 Using the Guide Light	
	16.2 Distance Setting-out Measurement	
	16.3 Coordinates Setting-out Measurement	
	16.4 REM Setting-out Measurement	
17.	OFFSET MEASUREMENT	
_	17.1 Offset Single-distance Measurement	

	17.2 Offset Angle Measurement	76
	17.3 Offset Two-distance Measurement	77
18.	. MISSING LINE MEASUREMENT	80
	18.1 Measuring the Distance between 2 or more Points	80
	18.2 Changing the Starting Point	82
19.	SURFACE AREA CALCULATION	
20.	. CHANGING THE SETTINGS	86
	20.1 Observation Conditions	86
	20.2 Instrument Configuration	88
	20.3 EDM Settings	90
	20.4 Allocating User-defined Tabs	93
	20.5 Customizing Screen Controls	95
	20.6 Allocating Key Functions	97
	20.7 Changing Starkey Mode Icons	99
	20.8 Unit	
	20.9 Date and Time	102
	20.10Changing Password	102
	20.11Restoring Default Settings	
	. WARNING AND ERROR MESSAGES	
22.	. CHECKS AND ADJUSTMENTS	
	22.1 Circular Level	
	22.2 Tilt Sensor	
	22.3 Collimation	
	22.4 Reticle	110
	22.5 Optical Plummet	
	22.6 Additive Distance Constant	
	22.7 Laser Plummet (Optional Accessory)	113
	POWER SUPPLY SYSTEM	
	TARGET SYSTEM	
	OPTIONAL ACCESSORIES	
	. SPECIFICATIONS	
27.	EXPLANATIONS	
	27.1 Manually Indexing the Vertical Circle by Face 1/2 Measurement	
	27.2 Correction for Refraction and Earth Curvature	
	REGULATIONS	
29.	. INDEX	130

1. PRECAUTIONS FOR SAFE OPERATION

For the safe use of the product and prevention of injury to operators and other persons as well as prevention of property damage, items which should be observed are indicated by an exclamation point within a triangle used with WARNING and CAUTION statements in this operator's manual.

The definitions of the indications are listed below. Be sure you understand them before reading the manual's main text.

Definition of Indication

\triangle	WARNING	Ignoring this indication and making an operation error could possibly result in death or serious injury to the operator.
W	CAUTION	Ignoring this indication and making an operation error could possibly result in personal injury or property damage.



This symbol indicates items for which caution (hazard warnings inclusive) is urged. Specific details are printed in or near the symbol.



This symbol indicates items which are prohibited. Specific details are printed in or near the symbol.



This symbol indicates items which must always be performed. Specific details are printed in or near the symbol.

General

Λ

Warning



Do not use the unit in areas exposed to high amounts of dust or ash, in areas where there is inadequate ventilation, or near combustible materials. An explosion could occur.



Do not perform disassembly or rebuilding. Fire, electric shock, burns, or hazardous radiation exposure could result.



Never look at the sun through the telescope. Loss of eyesight could result.

0

Do not look at reflected sunlight from a prism or other reflecting object through the telescope. Loss of eyesight could result.

0

Direct viewing of the sun during sun observation will cause loss of eyesight. Use solar filter (option) for sun observation.

A

When securing the instrument in the carrying case make sure to set all the locks. Failure to do so could result in the instrument falling out while being carried, causing injury.

\triangle

Caution

 \bigcirc

Do not use the carrying case as a footstool. The case is slippery and unstable so a person could slip and fall off it.

 \oslash

Do not place the instrument in a damaged case or in a case with a damaged belt. The case or instrument could be dropped and cause injury.

 \bigcirc

Do not touch the instrument or look through the telescope while the motor is in operation. Injury could result.

 \bigcirc

Do not wield or throw the plumb bob. A person could be injured if struck.

0

Secure handle to main unit. Failure to properly secure the handle could result in the unit falling off while being carried, causing injury.

0

Tighten the adjustment tribrach clamp securely. Failure to properly secure the clamp could result in the tribrach falling off while being carried, causing injury.

Power Supply

^
/1 \
/ • \

Warning



Do not disassemble or rebuild the battery or the battery charger, nor expose to heavy shocks or vibration. Sparking, fire, electric shock or burns could result.

 \bigcirc

Do not short circuit. Heat or ignition could result.

 \bigcirc

Do not place articles such as clothing on the battery charger while charging batteries. Sparks could be induced, leading to fire.

 \bigcirc

Do not use voltage other than the specified power supply voltage. Fire or electrical shock could result.

 \bigcirc

Do not use batteries other than those designated. An explosion could occur, or abnormal heat generated, leading to fire.

 \bigcirc

Do not use damaged power cords, plugs or loose outlets. Fire or electric shock could result.

 \Diamond

Do not use power cords other than those designated. Fire could result.

0

Use only the specified battery charger to recharge batteries. Other chargers may be of different voltage rating or polarity, causing sparking which could lead to fire or burns.

 \bigcirc

Do not use the battery or charger for any other equipment or purpose. Fire or burns caused by ignition could result.

(

Do not heat or throw batteries or chargers into fire. An explosion could occur, resulting in injury.

0

To prevent shorting of the battery in storage, apply insulating tape or equivalent to the terminals. Otherwise shorting could occur resulting in fire or burns.

 \sim

Do not use the battery or the battery charger if its terminals are wet. Resultant poor contact or shorting could lead to fire or burns.

 \langle

Do not connect or disconnect power supply plugs with wet hands. Electric shock could result.



Caution



Do not touch liquid leaking from batteries. Harmful chemicals could cause burns or blisters.

Tripod

A

Caution



When mounting the instrument to the tripod, tighten the centering screw securely. Failure to tighten the screw properly could result in the instrument falling off the tripod, causing injury.

0

Tighten securely the leg fixing screws of the tripod on which the instrument is mounted. Failure to tighten the screws could result in the tripod collapsing, causing injury.

 \bigcirc

Do not carry the tripod with the tripod shoes pointed at other persons. A person could be injured if struck by the tripod shoes.

0

Keep hands and feet away from the tripod shoes when fixing the tripod in the ground. A hand or foot stab wound could result.

A

Tighten the leg fixing screws securely before carrying the tripod. Failure to tighten the screws could lead to the tripod legs extending, causing injury.

Bluetooth wireless technology



Warning



Do not use within the vicinity of hospitals. Malfunction of medical equipment could result.



Use the instrument at a distance of at least 22 cm from anyone with a cardiac pacemaker. Otherwise, the pacemaker may be adversely affected by the electromagnetic waves produced and cease to operate as normal.



Do not use onboard aircraft. The aircraft instrumentation may malfunction as a result.



Do not use within the vicinity of automatic doors, fire alarms and other devices with automatic controls as the electromagnetic waves produced may adversely affect operation resulting in an accident.

Use under low temperatures (Low Temperature Model only)



Caution



In temperatures around -30°C do not touch metal parts on the main unit, the accessories and the carrying case with bare hands. Exposed skin may stick to parts and cause burns and loss of skin.

2. PRECAUTIONS

Charging Battery

• Be sure to charge the battery within the charging temperature range.

Charging temperature range : 0 to 40°C

• Use only the specified battery or the battery charger. Failures caused by using other batteries or battery chargers are out of warranty including the main unit.

(Battery: BDC72, Charger: CDC77)

Warranty policy for Battery

• Battery is an expendable item. The decline in retained capacity depending on the repeated charging/ discharging cycle is out of warranty.

Bluetooth Wireless Technology

• *Bluetooth* function may not be built in depending on telecommunications regulations of the country or the area where the instrument is purchased. Contact your local dealer for the details.


Telescope


• Aiming the telescope at the sun will cause internal damage to the instrument. Use the solar filter when observing the sun.

I "25. OPTIONAL ACCESSORIES"

Tribrach Clamp and Handle

• When the instrument is shipped, the tribrach clamp is held firmly in place with a locking screw to prevent the instrument from shifting on the tribrach. Before using the instrument the first time, loosen this screw with a precision screwdriver. And before transporting it, tighten the locking screw to fasten the tribrach clamp in place so that it will not shift on the tribrach.






Precautions concerning water and dust resistance

The instrument conforms to IP65 specifications for waterproofing and dust resistance when battery cover, connector cap and the external interface hatch are closed.

- Be sure to correctly attach the connector caps to protect the instrument from moisture and dust particles when the connector is not in use.
- Make sure that moisture or dust particles do not come in contact with the terminal or connectors.
 Operating the instrument with moisture or dust on the terminal or connectors may cause damage to the instrument.
- Make sure that the inside of the carrying case and the instrument are dry before closing the case. If moisture is trapped inside the case, it may cause the instrument to rust.
- If there is a crack or deformation in the rubber packing for the battery cover or external interface hatch, stop using and replace the packing.
- To retain the waterproof property, it is recommended that you replace the rubber packing once every two years. To replace the packing, contact your local dealer.
- Do not press the speaker / luminance sensor hole using something with a pointed tip.
 Doing so will damage an internal waterproof sheet, resulting in a degraded waterproof property.



The Lithium Battery

• The lithium battery is used to maintain the Calendar & Clock function. It can back up data for approximately 5 years of normal use and storage (Temperature = 20°, humidity = about 50%), but its lifetime may be shorter depending on circumstances. If the voltage supplied by the lithium battery declines, an error will be displayed. Ask your local dealer to replace the battery for you.

Vertical and horizontal clamps

• Always fully release the vertical/horizontal clamps when rotating the instrument or telescope. Rotating with clamp(s) partially applied may adversely affect accuracy.

Tribrach

• Always use the tribrach provided. During a traverse observation, it is recommended to use the same type of tribrach for the target as well for accurate observations.

Backing up data

• Data should be backed up (transferred to an external device etc.) on a regular basis to prevent data loss.

Use under low temperatures (Low Temperature Model only)

- Do not use force to scrape off frost from the lens or display unit screen. Frost is an abrasive material and may scratch the instrument.
- If ice or snow attaches itself to the unit, wipe it off with a soft cloth, or place the unit in a warm room until the ice melts, and then wipe off the meltwater. Operating the unit with ice or snow attached may cause operation errors to occur.
- Wipe off condensation with a soft cloth before using the instrument. Not doing so may cause operation errors to occur.
- The working duration of battery BDC72 will rapidly decline in cold temperatures. When using the instrument in temperatures around -30°C, we recommend that you use an external battery (optional accessory). However, if you unavoidably must use battery BDC72 for measurements in temperatures around -30°C, recharge the battery in a warm room and keep the battery in a warm place such as your pocket until it is used. (Working duration of battery will change with environmental conditions.)
- The lens cap and lens hood may become difficult to attach in low temperatures. Keep them in a warm place such as a pocket until attached.
- If the unit is carried between locations that have extreme temperature differences, protect the unit from rapid temperature change by placing it in the carrying case.
- Please use the tribrach supplied as standard. If a different tribrach is used, angle measurement errors may occur.

Other precautions

- Never place the instrument directly on the ground. Sand or dust may cause damage to the screw holes or the centering screw on the base plate.
- Do not perform vertical rotation of the telescope when using the lens hood, diagonal eyepiece, or solar filter. Such accessories may strike the instrument causing damage.
- Protect the instrument from heavy shocks or vibration.
- Protect the instrument from rain or drizzle with an umbrella or waterproof cover.
- Never carry the instrument on the tripod to another site.
- Turn the power off before removing the battery.
- When placing the FX in its case, first remove its battery and place it in the case in accordance with the layout plan.
- Make sure that the instrument and the protective lining of the carrying case are dry before closing the case. The case is hermetically sealed and if moisture is trapped inside, the instrument could rust.
- Consult your local dealer before using the instrument under special conditions such as long periods of
 continuous use or high levels of humidity. In general, special conditions are treated as being outside the scope
 of the product warranty.

Maintenance

- Wipe off moisture completely if the instrument gets wet during survey work.
- Always clean the instrument before returning it to the case. The lens requires special care. First, dust it off
 with the lens brush to remove tiny particles. Then, after providing a little condensation by breathing on the
 lens, wipe it with the silicon cloth.
- If the display is dirty, carefully wipe it with a soft, dry cloth. To clean other parts of the instrument or the carrying case, lightly moisten a soft cloth in a mild detergent solution. Wring out excess water until the cloth is slightly damp, then carefully wipe the surface of the unit. Do not use any alkaline cleaning solutions, alcohol, or any other organic solvents on the instrument or display.

For temporal de-activating the touch panel, see "5.2 Display Functions", "20. CHANGING THE SETTINGS"

- Store the instrument in a dry room where the temperature remains fairly constant.
- · Check the tripod for loose fit and loose screws.
- If any trouble is found on the rotatable portion, screws or optical parts (e.g. lens), contact your local dealer.
- When the instrument is not used for a long time, check it at least once every 3 months.

じ "22. CHECKS AND ADJUSTMENTS"

- When removing the instrument from the carrying case, never pull it out by force. The empty carrying case should be closed to protect it from moisture.
- Check the instrument for proper adjustment periodically to maintain the instrument accuracy.

Exporting this product (Relating EAR)

• This product is equipped with the parts/units, and contains software/technology, which are subject to the EAR (Export Administration Regulations). Depending on countries you wish to export or bring the product to, a US export license may be required. In such a case, it is your responsibility to obtain the license. The countries requiring the license as of Mar. 2020 are shown below. Please consult the Export Administration Regulations as they are subject to change.

North Korea

Iran

Syria

Sudan

Cuba

URL for the EAR of the US: http://www.bis.doc.gov/policiesandregulations/ear/index.htm

Exporting this product (Relating telecommunications regulations)

Wireless communication module is incorporated in the instrument. Use of this technology must be compliant
with telecommunications regulations of the country where the instrument is being used. Even exporting the
wireless communication module may require conformity with the regulations. Contact your local dealer in
advance.

Exceptions from responsibility

- The manufacturer, or its representatives, assumes no responsibility for any damage, or loss of profits (change
 of data, loss of data, loss of profits, an interruption of business etc.) caused by use of the product or an
 unusable product.
- The manufacturer, or its representatives, assumes no responsibility for any damage, or loss of profits caused by usage different to that explained in this manual.
- The manufacturer, or its representatives, assumes no responsibility for consequential damage, or loss of profits due to heavy rain, strong wind, high-temperature and humidity, or storing or use of the product under unusual conditions.
- Product failures caused by rebuilding are out of warranty.
- Cautions and warnings included in this manual do not cover all the possible events.

3. LASER SAFETY INFORMATION

The instrument is classified as the following class of Laser Product according to IEC Standard Publication 60825-1 Ed.3.0: 2014 and United States Government Code of Federal Regulation FDA CDRH 21CFR Part 1040.10 and 1040.11 (Complies with FDA performance standards for laser products except for deviations pursuant to Laser Notice No.56, dated May 8, 2019.)

	Device	Laser class
	Light beam used for measurement (When target (reflector) is set to N-prism.)	Class 3R
EDM device in objective lens	Light beam used for measurement (When target (reflector) is set to prism or reflective sheet.)	Class 1
	Laser-pointer	Class 3R
Laser plummet*1		Class2


^{*1:} Laser plummet is available as a factory option depending on the country or the area where the instrument is purchased.



• EDM device is classified as Class 3R Laser Product when reflectorless measurement is selected. When target (reflector) is set to prism or reflective sheet, the output is equivalent to the safer class 1.

∴Warning

- Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.
- Follow the safety instructions on the labels attached to the instrument as well as in this manual to ensure safe use of this laser product.



- Never intentionally point the laser beam at another person. The laser beam is injurious to the eyes and skin. If an eye injury is caused by exposure to the laser beam, seek immediate medical attention from a licensed ophthalmologist.
- Do not look directly into the laser beam source or guide light source. Doing so could cause permanent eye damage.
- Do not stare at the laser beam. Doing so could cause permanent eye damage.
- Never look at the laser beam through a telescope, binoculars or other optical instruments. Doing so could cause permanent eye damage.
- Sight targets so that the laser beam does not stray from them.


⚠ Caution

- Perform checks at start of work and periodic checks and adjustments with the laser beam emitted under normal conditions.
- When the instrument is not being used, turn off the power and replace the lens cap.
- When disposing of the instrument, destroy the battery connector so that the laser beam cannot be emitted.
- Operate the instrument with due caution to avoid injuries that may be caused by the laser beam unintentionally striking a person in the eye. Avoid setting the instrument at heights at which the path of the laser beam may strike pedestrians or drivers at head height.
- Never point the laser beam at mirrors, windows or surfaces that are highly reflective. The reflected laser beam could cause serious injury.
- Only those who have been received training as per the following items shall use this product.
 - · Read this manual for usage procedures for this product.
 - · Hazardous protection procedures (read this chapter).
 - · Requisite protective gear (read this chapter).
 - Accident reporting procedures (stipulate procedures beforehand for transporting the injured and contacting physicians in case there are laser induced injuries).
- Persons working within the range of the laser beam are advised to wear eye protection which corresponds to the laser wavelength of the instrument being used. (OD2)
- Areas in which the laser is used should be posted with a standard laser warning sign.
- When using the laser-pointer function, be sure to turn OFF the output laser after distance measurement is completed. Even if distance measurement is canceled, the laser-pointer function is still operating and the laser beam continues to be emitted.

4. PRODUCT OUTLINE

4.1 Parts of the Instrument


Parts and functions of the instrument



- 1 Handle
- 2 Bluetooth antenna
- 3 External interface hatch (USB port / Reset button)
 IT "10. CONNECTING TO EXTERNAL DEVICES"
- 4 Instrument height mark 🗊
- 5 Battery cover
- 6 Display unit
- 7A Serial connector
- 7B Serial / External power source connector
- 8 Circular level
- 9 Circular level adjusting screws
- 10 Base plate
- 11 Levelling foot screw
- 12 Optical plummet focussing ring
- 13 Optical plummet eyepiece
- 14 Optical plummet reticle cover
- 15 Luminance sensor
- 16 Guide light 0
- 17 Objective lens (Includes " Laser-pointer function")



- 19 Tubular compass slot
- 20 Vertical clamp
- 21 Vertical fine motion screw
- 22 Trigger key
- 23 Horizontal fine motion screw
- 24 Horizontal clamp
- 25 Tribrach clamp
- 26 Telescope eyepiece screw
- 27 Telescope focussing ring
- 28 Sighting collimator
- 29 Instrument center mark
- 30 Plate level
- 31 Plate level adjusting screw



FX-201/202 and low temperature models only



Low temperature models only



Instrument height mark

The height of the instrument is as follows:

- 192.5mm (from tribrach mounting surface to this mark)
- 236mm (from tribrach plate to this mark)


"Instrument height" is input when setting instrument station data and is the height from the surveying point (where the instrument is mounted) to this mark.

Laser-pointer function

A target can be sighted with a red laser beam in dark locations without the use of the telescope.

Guide light

Setting-out measurement etc. can be carried out effectively using the guide light. The guide light is composed of a light that is divided into green and red sections. A poleman can ascertain the present position by checking the guide light color.



Guide light status

Light status	Meaning
Increased flashing speed	(From position of poleman) Move target toward instrument
Decreased flashing speed	(From position of poleman) Move target away from instrument
Fast flashing	Target is at correct distance
Red	(From position of poleman) Move target left
Green	(From position of poleman) Move target right
Red and Green	Target is at correct horizontal position

The guide light indicator is lit or flashes depending on the status of the guide light.

"16.1 Using the Guide Light"

Sighting collimator


Use sighting collimator to aim the instrument in the direction of the measurement point. Turn the instrument until the apex of the triangle in the sighting collimator is aligned with the target. A circle surrounds the triangle to make it easier to locate.

Trigger key

When the Trigger key is pressed, the instrument carries out the operation indicated by the orange Operating icon on the screen. This allows the user to continue operation without having to return to the display to press Operating icons.

Bluetooth antenna (Models with Bluetooth module only)

The Bluetooth antenna allows communication via Bluetooth wireless technology.






• Handle the antenna with care. The antenna may be damaged if struck during operation or while being stored in the carrying case.

Handle

The carrying handle can be removed from the instrument. To remove it, loosen the handle rocking screw.




Detaching the instrument from the tribrach

- 1. Turn the tribrach clamp counterclockwise to loosen.
- 2. Lift the instrument to detach.

Attaching the instrument to the tribrach


- 1. Align (1) and (2) and lower the instrument onto the tribrach.
- 2. Turn the tribrach clamp clockwise to tighten.



4.2 Mode Structure

The diagram below describes the different modes of the instrument and key operations for navigating between them

Basic mode





- Switching between modes is not possible during distance measurement.
- Do not switch between modes by **{PRG}** or not turn OFF the power just after pressing **{PRG}** (during displaying the message "Executing program mode").

4.3 Bluetooth Wireless Technology



- *Bluetooth* function may not be built in depending on telecommunications regulations of the country or the area where the instrument is purchased. Contact your local dealer for the details.
- Use of this technology must be authorized according to telecommunications regulations of the country where the instrument is being used. Contact your local dealer in advance.
 "28. REGULATIONS"
- TOPCON CORPORATION is not liable for the content of any transmission nor any content related thereto. When communicating important data, run tests beforehand to ascertain that communication is operating normally.
- Do not divulge the content of any transmission to any third party.

Radio interference when using Bluetooth technology

Bluetooth communication with the FX uses the 2.4 GHz frequency band. This is the same band used by the devices described below.

- Industrial, scientific, and medical (ISM) equipment such as microwaves and pacemakers.
- · portable premises radio equipment (license required) used in factory production lines etc.
- portable specified low-power radio equipment (license-exempt)
- IEEE802.11b/IEEE802.11g/IEEE802.11n standard wireless LAN devices

The above devices use the same frequency band as *Bluetooth* communications. As a result, using the FX within proximity to the above devices may result in interference causing communication failure or reduction of transmission speed.

Although a radio station license is not required for this instrument, bear in mind the following points when using *Bluetooth* technology for communication.

Regarding portable premises radio equipment and portable specified low-power radio equipment:

- Before starting transmission, check that operation will not take place within the vicinity of portable premises radio equipment or specified low-power radio equipment.
- In the case that the instrument causes radio interference with portable premises radio equipment, terminate the connection immediately and take measures to prevent further interference (e.g. connect using an interface cable).
- In the case that the instrument causes radio interference with portable specified low-power radio equipment, contact your local dealer.

■ When using the FX in proximity to IEEE802.11b/IEEE802.11g/IEEE802.11n standard wireless LAN devices, turn off all devices not being used.

• Interference may result, causing transmission speed to slow or even disrupting the connection completely. Turn off all devices not being used.

Do not use the FX in proximity to microwaves.

• Microwave ovens can cause significant interference resulting in communication failure. Perform communication at a distance of 3m or more from microwave ovens.

Refrain from using the FX in proximity to televisions and radios.

• Televisions and radios use a different frequency band to *Bluetooth* communications. However, even if the FX is used within proximity to the above equipment with no adverse effects with regard to *Bluetooth* communication, moving a *Bluetooth* compatible device (including the FX) closer to said equipment may result in electronic noise in sound or images, adversely affecting the performance of televisions and radios.

Precautions regarding transmission

For best results

- The usable range becomes shorter when obstacles block the line of sight, or devices such as PDAs or computers are used. Wood, glass and plastic will not impede communication but the usable range becomes shorter. Moreover, wood, glass and plastic containing metal frames, plates, foil and other heat shielding elements as well as coatings containing metallic powders may adversely affect Bluetooth communication and concrete, reinforced concrete, and metal will render it impossible.
- Use a vinyl or plastic cover to protect the instrument from rain and moisture. Metallic materials should not be used.
- The direction of the *Bluetooth* antenna can have adverse effects upon usable range.

Reduced range due to atmospheric conditions

• The radio waves used by the FX may be absorbed or scattered by rain, fog, and moisture from the human body with the limit of usable range becoming lower as a result. Similarly, usable range may also shorten when performing communication in wooded areas. Moreover, as wireless devices lose signal strength when close to the ground, perform communication at as high a position as possible.




• TOPCON CORPORATION cannot guarantee full compatibility with all *Bluetooth* products on the market.

5. BASIC OPERATION

Learn basic key operations here before you read each measurement procedure.

5.1 Basic Key Operation



Power ON/OFF

{⊙}	Power ON
{⊕} (Press and hold: About 1 second)	Power OFF

Lighting up the reticle/keys and selecting screen backlight brightness

{∻}	Switches the reticle illumination and key light On/Off (When Key light is
[1	On, backlight brightness goes down)

Brightness level: "20.2 Instrument Configuration"

Switching to Starkey mode

{★}	Switches to Starkey mode/previous screen

\$\mathbb{L}\mathbb{F}\$ "5.4 Starkey Mode"

Switching to Program mode

{PRG}	Switches to Program mode/Basic mode
•	

¥

• Do not switch between modes by **{PRG}** or not turn OFF the power just after pressing **{PRG}** (during displaying the message "Executing program mode").

Switching target type

{⊗}	Switches between target types
	Prism/Sheet/N-prism (reflectorless)

"20.3 EDM Settings"

Note

Changes can also be made by tapping the icon on Status bar or in Starkey mode.
 "5.2 Display Functions", "5.4 Starkey Mode"

Switching the Laser-pointer/Guide light ON/OFF

{☆} (Press and hold)	To turn the laser-pointer/guide light ON/OFF, press and hold until a beep sounds.
----------------------	---

Note

• Changes can also be made by tapping the icon on Status icon or in Starkey mode.

"5.2 Display Functions", "5.4 Starkey Mode"

Switching the page

Inputting letters/figures

{ α }	Switch between numerals and alphabetic characters	
{SHIFT} + {1} to {9}	In alphabetic characters mode, switch between lowercase characters and upper case characters each time	
{SHIFT} (Press and hold)	In alphabetic characters mode, switch between lowercase characters and upper case characters	
{SHIFT} + {α}	Display/hide <input panel=""/>	
{0} to {9}	Input numeral or symbol printed above the key (during numeric input mode) Input alphabetic character in the order they are listed (in alphabetic input mode)	
{.}	Input a decimal point (during numeric input mode) Input code (in alphabetic input mode)	
{±}	Inputs a plus or minus sign (during numeric input mode) Inputs code (in alphabetic input mode)	
{ESC}	Cancel the input data	
{TAB}	Shift to the next item	
{B.S.}	Delete a character on the left.	
{S.P.}	Input a blank space (increments by 1 when setting the date and time)	
{ ₫ }/ ⟨▶ }	Move the cursor left/right	
{▲}/{▼}	Move the cursor up/down	
{ENT}	Select/accept input word/value	

Selecting options

{▲}/{▼}	Move the cursor/selection item up/down
{ ₫ }/ {▶ }	Move the cursor/selection item left/right or select other option
{TAB}	Shift to the next item
{S.P.}	Display other options
{ENT}	Select/accept the option

Selecting tabs

{▲}/{▼}	Move tab/cursor in tab up/down
{◀} / {▶ }	Display next tab at left/right

Others


{ESC}	Returns to previous screen

Example: Entering "computer" (lower case)


1. Tap the input mode icon in the status bar (second from bottom) until "_a" is displayed.



Press {7} three times."c" is displayed.



3. Press **{5}** three times. "o" is displayed.



4. Press **(▶)**. Press **(5)**. "m" is displayed.




5. Continue to input letters. Press **{ENT}** to complete inputting.

Example: selecting a reflector type


(Method 1)

1. Select **[EDM]** in the first page of Observation mode or "EDM" in Config mode/Configuration mode.

☐ • Observation mode screen SHV tab



- 2. Move to "Reflector" using $\{\triangle\}/\{\nabla\}/\{TAB\}$.
- 3. Press **{SPACE}** to display a list of all options.



- 4. Select an option using **(▲)**/**(▼)**.
- 5. Press **{ENT}** to confirm selection.

(Method 2)

- 1. Select [EDM] in the first page of Measure mode or "EDM" in Config mode/Configuration mode.
- 2. Move to "Reflector" using $\{\triangle\}/\{\nabla\}/\{TAB\}$.
- 3. Switch between Prism, Sheet, and N-Prism using {◀}/♠}.
- 4. Press **{ENT}** to confirm selection.

5.2 Display Functions

Screens can be operated using the keys on the keyboard or the touch panel. The touch panel can be operated using either the stylus pen provided or your fingers.

It is also possible to de-activate the touch panel temporarily.

"20. CHANGING THE SETTINGS"



• Do not scratch the display or use any sharp implement other than the stylus pen to operate the touch panel.

Using the stylus

The stylus pen can be used to select menus and buttons on the screen and operate the scroll bar.

Temporarily de-activating the touch panel

The touch panel can be temporarily de-activated. This is especially useful when cleaning the display. To de-activate, tap on the Status icon. <Touch panel temporarily de-activated> is displayed.



The touch panel cannot be operated while the above message is displayed. Press **{ESC}** to cancel the message and re-activate the touch panel.

Displaying and operating screens


- To close a screen, tap the cross in the top right corner, or press **{ESC}**.
- Tabs, softkey allocations, displayed tab items, and character sizes can all be changed in accordance with user preferences.

**20. CHANGING THE SETTINGS"


Top menu



Version display mode screen



Observation mode screen SHV tab



(1) Distance

Display status can be switched between SD (slope distance)/HD (horizontal distance)/VD (vertical distance).

20.1 Observation Conditions

(2) Vertical angle

The Vertical angle display can be switched between Zenith (Z=0°)/Horiz (H=0°)/Horiz (H=±90°) To switch vertical angle/slope in %, press **[ZA/%]** when allocated to the Observation mode screen. $\Box \mathcal{F}$ "20.1 Observation Conditions"

The capitalized letter in the softkey indicates the currently selected mode.

Allocating [ZA/%]: "20.6 Allocating Key Functions"

(3)Horizontal angle


Press **[R/L]** to switch the display status between HA-R (horizontal angle right)/HA-L (horizontal angle left). The capitalized letter in the softkey indicates the currently selected mode.

Allocating [R/L]: "20.6 Allocating Key Functions"


Note

• Horizontal distance and height difference are also displayed in "SHVdist" tab.


Measuring screen



Input screen/configuration screen



Observation mode screen Graphic tab



The "Graphic" tab display can be modified using the softkeys in the second page.

[CNFG]: In <Graphic configuration> the user can specify the orientation of the "graphic" tab display and


which point, target or station, to set at the center of the display.

[DEF.]: Returns to the original orientation display.

[ZoomIn]: Zooms in. [ZoomOut]: Zooms out.


Selecting menus

To select a menu, tap the touch panel or press the relevant number key.



Status bar

Indicates the current status of the instrument. Tapping icons will switch between the relevant options for that item. Tapping and holding will display a list of all available options for that item and, in certain cases, a link to the configuration screen for that item.



Allocation of the icons of the status bar corresponds with that of Starkey mode.

About icons: "5.4 Starkey Mode"


5.3 Inputting Characters using the Input Panel

To display <Input Panel>, tap $\fine 10^{\circ}$ of Status icon/Starkey mode or while pressing **{SHIFT}** press **{** α **}**. This keyboard can be used to input numeric and alphabetic characters as well as symbols. Tap the icon again to close.

Note

• When <Input Panel> is covering the / icon of the Status icon, use the stylus pen to drag the input panel to another part of the screen so that you can access the / icon.

Input panel



Esc : Deletes all input characters

Tab : Moves the cursor to the next text box

CAP : Alternates between upper and lower case alphabetic characters and numbers/symbols Shift : Alternates between upper and lower case alphabetic characters and numbers/symbols. Is

canceled after inputting a single character.

Ctl : No function

Del/← : Delete the character to the left/right or deletes the entire text in the active section

: Move the cursor left/rightENT : Accept input charactersSpace : Input a blank space

áü : Accesses further Latin/Germanic characters/symbols. Is canceled after inputting a single


character.

5.4 Starkey Mode

Via Starkey mode, you can jump from each Basic mode screen to the screen of checking/changing the various settings directly. Press starkey {★} to enter Starkey mode. Each icon can be tapped or pressed and hold in the same way with Status icon.

- 12 icons allocated in Starkey mode and the above 8 icons correspond with that Status icon
- · Allocation of the icons can be changed.

Changing allocation of Starkey mode: "20.7 Changing Starkey Mode Icons"



Indicates the current status of the instrument.

Tapping icons will switch between the relevant options for that item. Tapping and holding will display a list of all available options for that item and, in certain cases, a link to the configuration screen for that item.

Details of each icon are described below. (The numbers correspond to above icons).

(1) Battery icon

Remaining battery power indicator (BDC72/external battery BDC60B/61B, Temperature = 20°C, EDM on). The remaining battery power displayed when distance measurement is in progress may differ to that displayed at other times.

: Level 3 Full power

: Level 2 Plenty of power remains

: Level 1 Half or less power remains

[777]: Level 0 Little power remains Prepare a replacement battery. (Flashes red and black)

: No power

Stop operation and charge the battery. (Red display in the center of the screen) "7.1 Battery Charging"

When using external battery

Evel 3 Full power

Level 2 Plenty of power remains


i Level 1 Half or less power remains

: Level 0 Little power remains. Prepare a replacement battery.

7.1 Battery Charging

(2) Target type icon

Selection of target type and configuration of prism constant.



Target information can be edited/recorded in <Reflector setting>. "20.3 EDM Settings"

(3) PPM setting icon


Current atmospheric correction factor setting is displayed. Configuration of EDM.



(4) Laser-pointer/guide light icon

Configuration of laser-pointer/guide light status.

Switching the laser-pointer/guide light ON/OFF: "5.1 Basic Key Operation"




Note

• The laser-pointer will be automatically switched OFF during distance measurement.

(5) Tilt angle compensation icon

The vertical and horizontal angles are automatically compensated for small tilt errors using the dual-axis tilt sensor. This icon displays the status of this function.



• > is displayed when the instrument is out of level.

(6) Communication status with external devices icon

Selection of communication method with external devices. This icon is not displayed in Program mode. *Bluetooth* settings can only be selected when using instruments incorporating the *Bluetooth* module. You can jump to the Communication config. screen.

Setting of RS232C communication: "10.4 Connection via RS232C cable"

Setting of Bluetooth communication: "10.1 Wireless Communication using Bluetooth Technology"



: Connection via RS232C cable

: Connection via Bluetooth wireless technology (green antenna)

Connection status to external devices is displayed as follows.

i) Connection via Bluetooth wireless technology

: Connecting

: Canceling connection

: (Antenna is purple - stationary)

Communication settings in progress/Preparing for communication (Instrument just powered ON

etc.)

: Connection error (icon flashes) (the color depends on the setting)

ii) Pie: Connection via RS232C cable

Note

• An arrow (e.g. | is displayed to indicate that data transmission is in progress. A red arrow indicates that data transmission has failed and data needs to be sent again.

(7) Input mode icon

Selection of input mode

_1	Inputting numbers and symbols
_a	Inputting lower case alphabetic characters
_A	Inputting upper case alphabetic characters

"5.3 Inputting Characters using the Input Panel" ● Inputting letters/figures"

(8) Input panel icon

"5.3 Inputting Characters using the Input Panel"

(9) Config mode icon

Switch to Config mode.

120. CHANGING THE SETTINGS"

(10) Touch panel icon

De-activate the touch panel temporarily or go to Inst.config.



: Touch panel temporarily de-activated.

Note

• This icon cannot be operated during distance measurement, or during data transmission.

(11) Disk usage icon

Tap and hold disk icon to check the detail of the disk usage.

:Less than 20%

:20 to 50%

:More than 50%

Internal disk
Used space ???? KB
Free space ???? KB
Capacity ???? KB
Removable Disk
Used space ???? KB
Free space ???? KB
Capacity ???? KB

Internal Disk

Used space: Usage space of disk capacity of the instrument Free space: Free space of disk capacity of the instrument

Capacity: Disk capacity of the instrument

Removable Disk

Usage space of disk capacity of the external disk connected to the instrument Free space:

Free space of disk capacity of the external disk connected to the instrument

Capacity: Disk capacity of the external disk connected to the instrument



• "Removable Disk" is displayed only when an external disk is connected to the instrument.

6. INSERTING USB FLASH DRIVE




• When reading/writing data, do not remove the USB flash drive.

Note

- We recommend using the attached USB flash drive when transferring data from the USB port of the instrument. TOPCON CORPORATION cannot guarantee safe operation of USB flash drives other than those attached to the instrument.
- Even if the procedure of SD formatting enables any general USB flash drives to be recognized, TOPCON CORPORATION cannot guarantee safe operation of them.

PROCEDURE


1. Open the external interface hatch by sliding its button.



2. Insert the USB flash drive into the USB port 1.



 When using a USB flash drive with 4 metal terminals on the surface, insert it with the terminal facing backwards to avoid damaging the USB port.



3. Close the external interface hatch until a click is heard.

7. USING THE BATTERY

7.1 Battery Charging

Be sure to charge the battery fully before using it for the first time or after not using it for long periods.




- The charger will become rather hot during use. This is normal.
- Do not use or charge batteries other than those designated. (Battery: BDC72, Charger: CDC77)
- The charger is for indoor use only. Do not use outdoors.
- Batteries cannot be charged when the temperature is outside the charging temperature range. Be sure to charge the battery within the charging temperature range.
- Do not charge the battery just after charging is completed. Battery performance may decline.
- Remove batteries from the charger before putting into storage.
- When not in use, disconnect the power cable plug from the wall outlet.
- Store the battery in a dry room where the temperature is within the following ranges. For long-term storage, the battery should be charged at least once every six months.

Storage period	Temperature range
1 month or less	-20 to 50°C
1 month to 3 months	-20 to 40°C
3 months to 1 year	-20 to 20°C


• Batteries generate power using a chemical reaction and as a result have a limited lifetime. Even when in storage and not used for long periods, battery capacity deteriorates with the passage of time. This may result in the operating time of the battery shortening despite having been charged correctly. In this event, a new battery is required.

PROCEDURE

- Connect the power cable to the charger and plug the charger into the wall outlet.
- Mount the battery in the charger by matching the grooves on the battery with the guides on the charger.
 When charging starts, the lamp starts flashing in green.
 The lamp lights up in green when charging is finished.



3. Remove the battery and unplug the charger.



Note

• Slots 1 and 2:

The battery charger can hold and charge up to two batteries at the same time.

• Charging time (at 25°C, when two batteries are charged at the same time): BDC72: about 8 hours

(Charging can take longer than the times stated above when temperatures are either especially high or low).

· Charging lamp:

LED	Description
Green lamp flashing	On charge
Green lamp lit	Fully charged
Yellow lamp flashing	Battery temperature is out of charging temperature range. Charge the battery again within the charging temperature range. If the yellow lamp still does not stop flashing, contact your local dealer.
Off	The battery is not correctly mounted. Mount it again correctly. If the lamp is still off, contact your local dealer.
Red lamp lit	Charging is not being normally performed. There may be trouble with the charger or battery. Contact your local dealer.

7.2 Installing/Removing the Battery

Mount the charged battery.


Type of power source: "23. POWER SUPPLY SYSTEM"



- Use the attached battery (BDC72).
- Before removing the battery, turn off the power to the instrument. If the battery is removed while the power is switched on, a warm boot may occur. File and folder data may be lost as a result.
- Do not open the battery cover while the power is on.
- Do not damage the projected sensor inside the battery cover. Also, be careful not to shut the battery cover on your fingers.
- When installing/removing the battery, make sure that moisture or dust particles do not come in contact with the inside of the instrument.
- Remove batteries from the surveying instrument or charger before putting into storage.


PROCEDURE Mounting the battery

1. Slide the catches on the battery cover to open.





- Do not insert the battery inclined. Doing so may damage the instrument or battery terminals.
- 3. Close the battery cover. A click is heard when the cover is secure.



8. SETTING UP THE INSTRUMENT



• Mount the battery in the instrument before performing this operation because the instrument will tilt slightly if the battery is mounted after levelling.


8.1 Centering

PROCEDURE Centering with the optical plummet eyepiece


1. Make sure the legs are spaced at equal intervals and the head is approximately level.

Set the tripod so that the head is positioned over the survey point

Make sure the tripod shoes are firmly fixed in the ground.




Place the instrument on the tripod head.Supporting it with one hand, tighten the centering screw on the bottom of the unit to make sure it is secured to the tripod.




 Looking through the optical plummet eyepiece, turn the optical plummet eyepiece to focus on the reticle.
 Turn the optical plummet focussing ring to focus on the survey point.

Focussing on the survey point



4. Adjust the levelling foot screws to center the survey point in the optical plummet reticle.





PROCEDURE Centering with the laser plummet (Optional accessory)

1. Set up the tripod and affix the instrument on the tripod head.

18.1 Centering


2. Power ON the instrument.

19. POWER ON/OFF"


The electric circular level is displayed on the <Tilt>.

3. Press [L-ON].

The laser plummet beam will be emitted from the bottom of the instrument.



4. Use [-]/[+] on the second page to adjust the brightness of the laser.



- 5. Adjust the position of the instrument on the tripod until the laser beam is aligned with the center of the survey point.
- 6. Press [L-OFF] to turn the laser plummet off.
 Alternatively, press {ESC} to return to another screen.
 The laser plummet will switch off automatically.

Note


• Visibility of the laser spot may be affected when operating in direct sunlight. In this event, provide shade for the survey point.

8.2 Levelling

PROCEDURE


- 1. Adjust the levelling foot screws to center the survey point in the optical plummet reticle.
- Center the bubble in the circular level by either shortening the tripod leg closest to the offcenter direction of the bubble or by lengthening the tripod leg farthest from the offcenter direction of the bubble.
 Adjust one more tripod leg to center the bubble.


Turn the levelling foot screws while checking the circular level until the bubble is centered in the center circle.




The electric circular level is displayed on the <Tilt>.

"●" indicates the bubble in circular level. The range of the inside circle is ±1.5' and the range of the outside circle is ±6'.





- Center "●" in the circular level.
 When the bubble is in the center, proceed to step 7.
- 5. Turn the instrument until the telescope is parallel to a line between levelling foot screws A and B.




 Set the tilt angle to 0° using foot screws A and B for the X direction and levelling screw C for the Y direction. Loosen the centering screw slightly.
 Looking through the optical plummet eyepiece, slide the instrument over the tripod head until the survey point is exactly centered in the reticle.

 Retighten the centering screw securely.

If the instrument is levelled using laser plummet, emit the laser plummet beam and check it again.

""8.1 Centering" " PROCEDURE Centering with the laser plummet (Optional accessory)"

- Check again to make sure the bubble in the electric circular level is centered.
 If not, repeat the procedure starting from step 6.
- 9. Press **{ESC}** to return to Observation mode.



9. POWER ON/OFF



· When the power cannot be switched ON or the power is soon turned OFF even though the battery is mounted, there may be almost no battery power remaining. Replace it with a fully charged battery. "21. WARNING AND ERROR MESSAGES"

PROCEDURE Power ON

Press { ⊕ }.

When the power is switched on, the <Tilt> is displayed.

\$\mathbb{L}\mathbb{F}\$ "8.2 Levelling" step 3

Press **{ESC}** to go to Observation mode.

If "Out of range" is displayed, the instrument tilt sensor is indicating that the instrument is out of level. Level the instrument once again using circular level, then display <Tilt>.

Press and hold Tilt angle compensation icon on status bar or in Starkey mode, then select "Go to Tilt screen". "5.4 Starkey Mode" (5) Tilt angle compensation icon

Note

• "Tilt crn." in "Obs. condition" should be set to "No" if the display is unsteady due to vibration or strong wind. "20.1 Observation Conditions"



Resume function

The Resume function redisplays the screen appearing before the instrument was powered OFF when the instrument is powered back ON. All parameter settings are also saved. Even if remaining battery power is completely depleted, this function will remain active for 1 minute, after which it is canceled. Replace a depleted battery as soon as possible.

PROCEDURE Power OFF

1. Press { ① } and hold (about 1sec).



- When there is almost no battery power remaining, the battery icon in the status bar will start to blink.In this event, stop measurement, switch off the power and charge the battery or replace with a fully charged battery.
- To save power, power to the instrument is automatically cut off if it is not operated for a fixed period of time. This time period can be set in "Power off" in <Inst.config.>.

"20.2 Instrument Configuration"

9.1 Configuring the Touch Panel


When using for the first time, or after performing a cold boot, the screen for configuring the touch panel will be displayed.

Follow the instructions on the screen and tap the crosshairs displayed on the screen with the stylus pen. Tap the cross-hairs on the other side of the display as well. Tap the cross-hairs on the other side of the display as well. (For the model with display on the both sides only).

Note

 Touch panel configuration can be performed at any time during normal operation by pressing [PNL CAL] in <Display>.

20.2 Instrument Configuration



9.2 Resolving Software Issues

If you are experiencing problems with the instrument and suspect a fault in the program, you should try a warm boot. If the problem is not resolved with a warm boot the next step is to perform a cold boot. A warm boot will not erase surveying data in the instrument but will cancel the resume function. Whenever possible transmit the data to a personal computer before rebooting.

PROCEDURE

- 1. Power OFF the instrument.
- 2. Press {①} while pressing **{ENT}**. The instrument is reset and powers ON as normal.

Cold boot

If the problem is not resolved with a warm boot the next step is to perform a cold boot. A cold boot will not erase surveying data in the instrument but all the parameters will be changed to the factory settings. If the data in the memory is necessary, **BE SURE TO TRANSFER IT TO A PERSONAL COMPUTER BEFORE PERFORMING A COLD BOOT.**

To perform a cold boot, while holding $\{ \not \cong \}$, and $\{ S.P. \}$, press $\{ \oplus \}$.

The instrument is reset and powers ON as normal.


"20.11 Restoring Default Settings"

Problems Powering OFF

When the instrument cannot be powered OFF as normal, depress the reset button with the tip of the stylus pen.



Pressing the Reset button may result in file and folder data being lost.



10.CONNECTING TO EXTERNAL DEVICES

The instrument supports *Bluetooth* wireless technology, USB and RS232C for communication with data collectors etc. Inputting/outputting data is also possible by inserting a USB flash drive or by connecting to a USB device.

Read this manual in conjunction with the operator's manual for the relevant external device.



- Bluetooth communication is only possible with instruments incorporating the Bluetooth module.
- When doing Bluetooth communication, read "4.3 Bluetooth Wireless Technology".

10.1 Wireless Communication using *Bluetooth* Technology

The *Bluetooth* module incorporated in the instrument can be used for communication with *Bluetooth* devices such as data collectors.

Configuration

1.Obs.condition

2.Inst.config

C 3.Inst.cons.

2▶ 4.EDM

🗐 5.Comms


PROCEDURE Setting for Bluetooth communication

1. Select "Comms" in Config mode.

Set Comms mode in the "Comms setup" tab to "Bluetooth".



- Changing communication settings during *Bluetooth* communication will cancel the connection.
- The status bar icon cannot be tapped in <Communication Setup>.
- No changes for the setting' (2) to (4) from the factory setting are necessary as long as connecting to a recommended program on the data collector. If connection can not be established, check the communication settings of the instrument and the data collector.
- Setting' (3) and (4) are for an instrument using GTS commands.



6.Units

7.Customize

9.Date & Time

8.Password

×

0

10

∰.@ _1

7

Items set and options (*: Factory setting)

(1) Communication mode RS232C*/Bluetooth

(2) Check sum yes/No*

(3) Terminate ETX*/ETX+CR/ETX+CR+LF

(4) Ack mode Off/On*

Terminate

Select the option Off or On for carriage return (CR) and line feed when collecting measurement data with a computer.

ACK mode

When communicating to an external device, the protocol for handshaking can omit the **[ACK]** coming from the external device so data is not sent again.


On: Standard
Off: Omit the [ACK]

2. Press the "Bluetooth" tab to display information for the FX. Register the *Bluetooth* address (BD ADDR) displayed here in the paired device.



- Do not start the Bluetooth connection on the right screen.
- 3. Press [OK] to finish settings. Move on to the Bluetooth communication.

10.2 Communication between the FX and Companion Device"



| D | Bluetooth device address

This is a number unique to one particular *Bluetooth* device used to identify devices during communication. This number consists of 12 characters (numbers 0 to 9 and letters from A to F). Some devices may be referred to by their Bluetooth device address.

Communication between the FX and Companion Device 10.2



- · Bluetooth communication causes instrument battery power to be depleted at a rate higher than that for normal operation.
- Check that the companion device (data collector, computer, or cellular phone etc.) is turned on and the relevant Bluetooth settings are complete.
- · All communication settings will be changed to factory settings when a cold boot is performed. Comms setup will need to be performed again.

"10.1 Wireless Communication using Bluetooth Technology"

PROCEDURE

1. Complete the necessary FX settings for Bluetooth communication.

10.1 Wireless Communication using Bluetooth Technology" " PROCEDURE Setting for Bluetooth communication"

- 2. Start communication by the data collector.
 - Manual of the program mounted on the data collector



• If prompted for a passkey, enter 0000 (four zeros).

When a connection has been successfully established, 🔒 is displayed.



 If the Bluetooth connection fails even though the communication environment is good, boot in the Bluetooth initialize mode.

To boot in a Bluetooth initialize mode, while holding $\{ \not \Rightarrow \}$, and $\{TAB\}$, press $\{ \oplus \}$. The message "Bluetooth Initialize Mode Are you sure?" is displayed on the screen.

After **[YES]** is pressed the instrument powers ON and the Top menu is displayed.

- Booting in the Bluetooth initialize mode will change the Bluetooth address.
- 3. Terminate the connection by the data collector.




- Immediately after disconnecting Bluetooth communication, you may not be able to reconnect.
 In such a case, please wait for several tens of seconds and then try to reconnect.
- If the Bluetooth connection is disconnected due to out of communication range or obstacles, it may take up to several tens of seconds to automatically reconnect.

10.3 Connecting to USB devices

FX has two different USB ports.



- TOPCON CORPORATION cannot guarantee that all USB devices are compatible with the FX USB ports.
- Use a computer Windows 7/10 is based and USB connection is capable.



Each port is used for connection to different types of devices.

Port name	Device type
USB port 1	USB flash drive
USB port 2 (mini-B)	computers etc.

Using USB port 2, the instrument and a computer can be communicated.



• Remove the USB cable from USB port 2 carefully to avoid damaging the cable.

Connecting the instrument to a computer to transfer data from the instrument

 Power OFF the instrument. Connect the USB port 2 on the instrument and computer using the USB cable.


"9. POWER ON/OFF"

Note

- The computer does not need to be turned OFF before connection.
- Press { ① } while pressing {ENT} to display a message box asking whether to boot USB mode, then press [YES].
 The display on the instruments shows <USB Mode> and the computer screen shows <Removable Disk>.

Note

• FX may not be displayed as <Removable Disk>. It depends on Windows settings.






Follow the instructions below to ensure that the instrument continues to operate normally during USB transfer.

- Do not change the folder hierarchy or folder names in <Removable Disk>.
- Do not format the "removable disk" on the computer.
- 3. Perform "Safely Remove Hardware" in the task bar and disconnect the USB cable.
- 4. Press () and hold (about 1sec) to turn off the instrument to exit USB mode connection.

10.4 Connection via RS232C cable

PROCEDURE Basic cable settings

- Connect the cable.
 Cables: "25. OPTIONAL ACCESSORIES"
- Select "Comms" in Config mode.
 Set communication conditions in the "Comms setup" tab. Set "Comms mode" to "RS232C".



3. Set options in the "RS232C" tab according to the selection made in the "Comms setup" tab.

*: factory settings


Baud rate: 1200/2400/4800/9600*/19200/

38400bps

Data bits: 7/8* bits

Parity: Not set*/Odd/Even

Stop bit: 1*/ 2 bits



11.FOCUSSING AND TARGET SIGHTINGS



· When sighting the target, strong light shining directly into the objective lens may cause the instrument to malfunction. Protect the objective lens from direct light by attaching the lens hood. Observe to the same point of the reticle when the telescope face is changed.

PROCEDURE

1. Focus on the reticle

Look through the telescope eyepiece at a bright and featureless background.

Turn the eyepiece screw clockwise, then counterclockwise little by little until just before the reticle image becomes focussed. Using these procedures, frequent reticle refocussing is not necessary since your eye is focussed at infinity.



2. Sight the target

Loosen the vertical and horizontal clamps, then use the sighting collimator to bring the target into the field of view. Tighten both clamps.

3. Focus on the target

Turn the telescope focussing ring to focus on the target. Turn the vertical and horizontal fine motion screws to align the target with the reticle.

The last adjustment of each fine motion screw should be in the clockwise direction.

4. Readjust the focus until there is no parallax

Readjust the focus with the focussing ring until there is no parallax between the target image and the reticle.



This is the relative displacement of the target image with respect to the reticle when the observer's head is moved slightly before the eyepiece.

Parallax will introduce reading errors and must be removed before observations are taken. Parallax can be removed by refocussing the reticle.

12.ANGLE MEASUREMENT

This section explains the procedures for basic angle measurement in Observation mode.

• It is possible to allocate Operating icons in measurement menus to suit various applications and the ways that different operators handle the instrument.

"20.6 Allocating Key Functions"

12.1 Measuring the Horizontal Angle between Two Points (Horizontal Angle 0°)


Use the "0SET" function to measure the included angle between two points. The horizontal angle can be set to 0 at any direction.

PROCEDURE


Sight the first target as at right.
 "11. FOCUSSING AND TARGET SIGHTINGS"




Press [0SET].
 [0SET] will flash, so press [0SET] again.
 The horizontal angle at the first target becomes 0°.



3. Sight the second target.



The displayed horizontal angle (HA-R) is the included angle between two points.





12.2 Setting the Horizontal Angle to a Required Value (Horizontal Angle Hold)


You can reset the horizontal angle to a required value and use this value to find the horizontal angle of a new target.

PROCEDURE

- 1. Sight the first target.
- 2. In the second page of Observation mode, press [H-SET]. <Set H angle> is displayed.
- Enter the angle you wish to set, then press [OK]. The value that is input as the horizontal angle is displayed.
 - The same setting can also be performed with coordinate and azimuth input.
 "14.2 Azimuth Angle Setting"







 Sight the second target.
 The horizontal angle from the second target to the value set as the horizontal angle is displayed.

Note

- Pressing [HOLD] performs the same function as above.
- Press **[HOLD]** to set the displayed horizontal angle. Then, set the angle that is in hold status to the direction you require.
 - Allocating [HOLD]: "20.6 Allocating Key Functions"

12.3 Angle measurement and Outputting the Data

The following explains angle measurement and the features used to output measurement results to a computer or other external devices.

Setting procedures: "10. CONNECTING TO EXTERNAL DEVICES"

Cables: "25. OPTIONAL ACCESSORIES"

Output format and command operations: "Communication manual"

PROCEDURE

- 1. Connect instrument and external device.
- 2. Allocate the **[HVOUT-T]** or **[HVOUT-S]** softkey to the Observation mode screen.

20.6 Allocating Key Functions"

Note

 Pressing the Operating icon outputs data in the following format.

[HVOUT-T] : GTS format [HVOUT-S] : SET format

- 3. Sight the target point.
- 4. Press [HVOUT-T] or [HVOUT-S].

Output measurement data to peripheral equipment.

13.DISTANCE MEASUREMENT

Perform the following settings as preparation for distance measurement in Observation mode.

- · Distance measurement mode
- Target type
- · Prism constant correction value
- ppm
- EDM ALC

"20.2 Instrument Configuration"

• It is possible to allocate softkeys in measurement menus to suit various applications and the ways that different operators handle the instrument.

"20.6 Allocating Key Functions"

• When using the laser-pointer function, be sure to turn OFF the output laser after distance measurement is completed. Even if distance measurement is canceled, the laser-pointer function is still operating and the laser beam continues to be emitted.



- Make sure that the target setting on the instrument matches the type of target used. The instrument automatically adjusts the intensity of the laser beam and switches the distance measurement display range to match the type of target used. If the target does not correspond to the target settings, accurate measurement results cannot be obtained.
- Accurate measurement results cannot be obtained if the objective lens is dirty. Dust it off with the lens brush first, to remove minute particles. Then, after providing a little condensation by breathing on the lens, wipe it off with the wiping cloth.
- During reflectorless measurement, if an object obstructs the light beam used for measurement or an object with a high reflective factor (metal or white surface) is positioned behind the target, accurate measurement results may not be received.
- Scintillation may affect the accuracy of distance measurement results. Should this occur, repeat measurement several times and use the averaged value of the obtained results.

13.1 Returned Signal Checking

Check to make sure that sufficient reflected light is returned by the target sighted by the telescope. Checking the returned signal is particularly useful when performing long distance measurements.

⚠ Caution


The laser beam is emitted during returned signal checking.



When the light intensity is sufficient even though the center of the reflective prism and the reticle are slightly
misaligned (short distance etc.), "
 "will be displayed in some cases, but in fact, accurate measurement is
impossible. Therefore make sure that the target center is sighted correctly.

PROCEDURE

- 1. Accurately sight the target.
- Press [S-LEV] in Observation mode.
 <Aiming> is displayed.
 Allocating [S-LEV]: "20.6 Allocating Key Functions"



When **[S-LEV]** is pressed, a gauge indicating light intensity is displayed.

- The more displayed, the greater the quantity of reflected light.
- If "
 " is displayed, only enough light for the measurement is returned.
- When "
 " is not displayed, accurately resight the target.

[BEEP]/[OFF]: Sets a buzzer sound when measurement is possible. Press to switch on and off. [MEAS]: Returns to Observation mode and starts angle and distance measurement.

 Press [OFF] to finish signal checking.
 Press {ESC} or tap the cross in the top-right corner to return to the previous screen.



- When is displayed persistently, but "•" is not, contact your local dealer.
- If no key operations are performed for two minutes, the display automatically returns to the previous screen.

13.2 Distance and Angle Measurement

An angle can be measured at the same time as distance.

PROCEDURE

Face the instrument in the direction of the target
 Use the sighting collimator to aim the instrument and
 telescope toward the target.

☐ "11. FOCUSSING AND TARGET SIGHTINGS"

2. Start measurement.


Press [MEAS] in the first page of Observation mode to start measurement.

SHVdist Graphic

Basic observation

SHV

The measured distance data (SD), vertical angle (ZA), and horizontal angle (HA-R) are displayed.



3. Press [STOP] to quit distance measurement.

Note

- If the single measurement mode is selected, measurement automatically stops after a single measurement.
- During fine average measurement, the distance data is displayed as SD1, SD2,... to SD9. When the designated number of measurements has been completed, the average value of the distance is displayed in the "SDA" line.
- If the tracking measurement is conducted with the target type "N-Prism", the measured data for a distance exceeding 250m is not displayed.
- The distance and angle that are most recently measured remain stored in the memory until the power is off and can be displayed at any time by pressing **[CALL]**.

13.3 Distance Measurement and Outputting the Data

The following explains distance measurement and the features used to output measurement data to a computer or external devices.

Setting procedures: "10. CONNECTING TO EXTERNAL DEVICES"

Cables: "25. OPTIONAL ACCESSORIES"

Output format and command operations: "Communication manual"

PROCEDURE

- 1. Connect instrument and external device.
- 2. Sight the target point.
- 3. Press [HVDOUT-T] or [HVDOUT-S] to measure the distance and output the data to the external device.
- 4. Press **[STOP]** to stop outputting data and return to Observation Mode.


13.4 REM Measurement

An REM measurement is a function used to measure the height to a point where a target cannot be directly installed such as power lines, overhead cables and bridges, etc.

The height of the target is calculated using the following formula.

Ht =
$$h_1 + h_2$$

 $h2 = S \sin \theta_{z1} x \cot \theta_{z2} - S \cos \theta_{z1}$




• It is possible to allocate softkeys in measurement menus to suit various applications and the ways that different operators handle the instrument.

"20.6 Allocating Key Functions"


PROCEDURE

 Set the target directly under or directly over the object and measure the target height with a tape measure etc.


Press [HT] and enter the target height.




2. Select "REM" in <Menu>.




Sight the target and press [MEAS] to start measurement. Press [STOP] to stop the measurement.



The measured distance data, vertical angle and horizontal angle are displayed.



- 4. Sight the object, then press [REM] to start REM measurement is started. The height from the ground to the object is displayed in "Ht.". Press [STOP] to stop the measurement.
 - To re-observe the target, sight the target then press **[MEAS]**.
 - To continue REM measurement, press [REM].




Note

• When measurement data already exists, select "REM" in <Menu> as in step 2 to proceed to step 4 and start REM measurement. Press [STOP] to stop the measurement.

14.COORDINATE MEASUREMENT

By performing coordinate measurements it is possible to find the 3-dimensional coordinates of the target based on station point coordinates, instrument height, target height, and azimuth angles of the backsight station which are entered in advance.



 It is possible to allocate softkeys in measurement menus to suit various applications and the ways that different operators handle the instrument.
 "20.6 Allocating Key Functions"

14.1 Entering Instrument Station Data


Before performing coordinate measurement, enter instrument station coordinates and instrument height.

Note


• "Occupy" on the software represents instrument station.

PROCEDURE


- 1. First measure the instrument height with a tape measure, etc.
- 2. Select "Coord." in <Menu>.



3. Select "Occupy setup" and enter instrument station coordinates,instrument height (HI) and target height (HR).




4. Press **[OK]** to set the input values. <Set H angle> is displayed again.




14.2 Azimuth Angle Setting

Based on the instrument station coordinates and backsight station coordinates which have already been set, the azimuth angle of the backsight station is calculated.




PROCEDURE Entering coordinates


- Select "Backsight setup" in <Coordinate>. <Set H angle> is displayed.
 - Set H angle> can also be displayed from the screen in step 4 of "14.1 Entering Instrument Station Data".



2. Select the "Key in coord" tab and enter the backsight station coordinates.



 When checking backsight distance, sight the backsight station and press [MEAS]. Press [STOP] to display the distance calculated from coordinates, the measured distance, and the difference between the two. Press [YES] to set the azimuth angle and display <Coord. measurement>.




- [Azimuth]: Switches horizontal angle setting method.

 [] "14.2 | Horizontal angle settings"
- 3. Press **[OK]** to set the azimuth angle. <Coord. measurement> is displayed.

PROCEDURE Entering angle

- Select "Backsight setup" in <Coordinate>. <Set H angle> is displayed.
 - <Set H angle> can also be displayed from the screen in step 4 of "14.1 Entering Instrument Station Data".
- 2. Select the "Key in angle" tab and enter the desired angle in "H.ang".




3. Press **[OK]** to set the input values. <Coord. measurement> is displayed.

PROCEDURE Entering azimuth

- Select "Backsight setup" in <Coordinate>.<Set H angle> is displayed.
 - <Set H angle> can also be displayed from the screen in step 4 of "14.1 Entering Instrument Station Data".

- 2. Select the "Key in azimuth" tab and enter the desired angle in "Azimuth".
 - [Azimuth]: Switches horizontal angle setting method.

Horizontal angle settings"



Press [OK] to set the input values. <Coord. measurement> is displayed.

Horizontal angle settings

Azimuth (set both horizontal and azimuth angles to the same value)/H.ang (input both horizontal and azimuth angles)/None (input azimuth angle only)/0 SET (horizontal angle set to 0°)

14.3 3-D Coordinate Measurement

The coordinate values of the target can be found by measuring the target based on the settings of the instrument station and backsight station.

The coordinate values of the target are calculated using the following formula.

N1 Coordinate = N0 + S x sinZ x cosAz

E1 Coordinate = E0 + S x sinZ x sinAz


Z1 Coordinate = $Z0 + S \times cosZ + ih - th$

N0: Station point N coordinateS: Slope distance ih: Instrument height

E0: Station point E coordinateZ: Zenith angle th: Target height


Z0: Station point Z coordinateAz: Direction angle

"Null" coordinates will not be included in calculations. "Null" is not the same as zero.




PROCEDURE

- 1. Sight the target at the target point.
- 2. Select "Coord." in <Coordinate>.



Press **[MEAS]** to start measurement. Press **[STOP]** to stop the measurement. The coordinates of the target point are displayed. Select the "Graphic" tab to display coordinates on a graph.



- 3. Sight the next target and press [MEAS] to begin measurement. Continue until all targets have been measured.
- 4. When coordinate measurement is completed, press **{ESC}** or tap the cross in the top-right corner to return to <Coordinate>.


15.RESECTION MEASUREMENT

Resection is used to determine the coordinates of an instrument station by performing multiple measurements of points whose coordinate values are known. Registered coordinate data can be recalled and set as known point data. Residual of each point can be checked, if necessary.

Entry Output

Coordinates of known point : (Ni, Ei, Zi) Station point coordinates : (N0,E0, Z0)

Observed horizontal angle : Hi
Observed vertical angle : Vi
Observed distance : Di



- Between 2 and 10 known points can be measured by distance measurement, and between 3 and 10 known points by angle measurement.
- The more known points there are and the more points there are whose distance can be measured, the higher the precision of the coordinate value calculation.
- It is possible to allocate softkeys in measurement menus to suit various applications and the ways that different operators handle the instrument.


"20.6 Allocating Key Functions"

15.1 Coordinate Resection Measurement

N, E, Z of an instrument station is determined by the measurement.

PROCEDURE

1. Select "Resection" in <Menu>.



0

_1 52

1240.586

1234,000

1233.690

0.000||m

OK

2. Select "NEZ" to display <Resection/Known point>.



Resection/Known point

11

PREV

Known Pt.id

North

East

Elev.

HR

- 3. Input the known point.
 - After setting the coordinates and target height for the first known point press **[NEXT]** to move to the second point.
 - Press **[PREV]** to return to settings for the previous point.

When all required known points have been set, press **[OK]**.

4. Sight the first known point and press **[MEAS]** to begin measurement.


The measurement results are displayed on the screen.

• When **[ANGLE]** has been selected, the distance cannot be displayed.

Resection/Observation known points Known Pt.id 1 0 North 1240.586 East 1234.000 Elev. 1233.690 SD 1.865 m 90°43'22" ZA. 249°01'55" HA-R ANGLE: **MEAS**


NEXT

- 5. Press **[YES]** to use the measurement results of the first known point.
 - You can also input target height here.
 - Press **[NO]** to return to the screen in step 4 and perform measurement again.




6. Repeat procedures 4 to 5 in the same way from subsequent points.


When the minimum quantity of observation data required for the calculation is present, **[CALC]** is displayed.




- 7. Press [CALC] or [YES] to automatically start calculations after observations of all known points are completed.
 - Instrument station coordinates, station elevation, and standard deviation, which describes the measurement accuracy, are displayed.



Standard deviation for the northing, easting and elevation coordinates of each point are displayed in the "Detail" tab.



8. If there are problems with the results of a point, align the cursor with that point and press **[OMIT]**. "OMIT" is displayed to the right of the point. Repeat for all results that include problems.




Press [RE_CALC] to perform calculation again without the point designated in step 8. The result is displayed.

If there are no problems with the result, go to step 10. If problems with the result occur again, perform the resection measurement from step 4.


• Press [RE OBS] to measure the point designated in step 8.

If no points are designated in step 8, all the points or only the final point can be observed again.

 Press [ADD] in the second page when there is a known point that has not been observed or when a new known point is added.



- 10. Press **[OK]** in <Resection/result> to display <Resection/Set h angle>.
- 11. Select an angle mode and press **[YES]** to set the azimuth angle of the first known point as the backsight point and return to <Resection/Menu>.
- 12.Press **[NO]** to return to <Resection/Menu> without setting the azimuth angle.



Horizontal angle settings

H (set horizontal angle to measured value)/H=Az (set horizontal angle to the same value as azimuth angle)/Az (set azimuth angle only)

Note

• It is also possible to perform resection measurement by pressing **[RESEC]** in the third page of Observation mode.


15.2 Height Resection Measurement

Only Z (height) of an instrument station is determined by the measurement.

- Known points must be measured by distance measurement only.
- Between 1 and 10 known points can be measured.

PROCEDURE

1. Select "Resection" in <Menu>.




2. Select "Elevation" to display <Resection/Known point>.



- Input the known point.
 After setting the elevation and target height for the first known point press [NEXT] to move to the second point.
 - Press **[PREV]** to return to settings for the previous point.


When all required known points have been set, press **[OK]**.




4. Sight the first known point and press **[MEAS]** to begin measurement.


The measurement results are displayed on the screen.

5. If measuring two or more known points, repeat procedures 4 in the same way from the second point.







- 6. Press **[CALC]** or **[YES]** to automatically start calculations after observations of all known points are completed.
 - Instrument station elevation and standard deviation, which describes the measurement accuracy, are displayed in the "Result" tab.



Standard deviation values for each point are displayed in the "Detail" tab.



7. If there are problems with the results of a point, align the cursor with that point and press **[OMIT]**. "OMIT" is displayed to the right of the point. Repeat for all results that include problems.



8. Press [RE CALC] to perform calculation again without the point designated in step 7 The result is displayed.

If there are no problems with the result, go to step 9. If problems with the result occur again, perform the resection measurement from step 4.

• Press [RE_OBS] to measure the point designated in step 7.


If no points are designated in step 7, all the points or only the final point can be observed again.



- Press [ADD] in the second page when there is a known point that has not been observed or when a new known point is added.
- Press [OK] to finish resection measurement and return to <Resection/Menu>. Only Z (elevation) of the instrument station coordinate is set. N and E values are not overwritten.

Resection calculation process

The NE coordinates are found using angle and distance observation equations, and the instrument station coordinates are found using the method of least squares. The Z coordinate is found by treating the average value as the instrument station coordinates.



Precaution when performing resection

In some cases it is impossible to calculate the coordinates of an unknown point (instrument station) if the unknown point and three or more known points are arranged on the edge of a single circle.

An arrangement such as that shown below is desirable.



It is sometimes impossible to perform a correct calculation in a case such as the one below. When they are on the edge of a single circle, take one of the following measures.



(1) Move the instrument station as close as possible to the center of the triangle.



(2) Observe one more known point which is not on the circle.



(3) Perform a distance measurement on at least one of the three points.





• In some cases it is impossible to calculate the coordinates of the instrument station if the included angle between the known points is too small. It is difficult to imagine that the longer the distance between the instrument station and the known points, the narrower the included angle between the known points. Be careful because the points can easily be aligned on the edge of a single circle.

16.SETTING-OUT MEASUREMENT

Setting-out measurement is used to set out the required point.

The difference between the previously input data to the instrument (the setting-out data) and the measured value can be displayed by measuring the horizontal angle, distance or coordinates of the sighted point.

The horizontal angle difference distance difference, and coordinate difference are calculated and displayed using the following formula.

Horizontal difference

Displayed value (angle) = Horizontal angle of setting-out data - measured horizontal angle

Displayed value (distance) = measured horizontal distance x tan

(horizontal angle of setting out data - measured horizontal angle)

Slope distance difference

Displayed value (slope distance) * = measured slope distance - slope distance setting-out data

* Horizontal distance or height difference can be input in the above formula.

Coordinate difference

Displayed value (coordinates)* measured N setting-out coordinates - N coordinates of setting-out data

* E or Z coordinates can be input in the above formula

Height difference (REM setting out measurement)

Displayed value (height) = measured REM data - REM data of setting out data

- Setting out data can be input in various modes: slope distance, horizontal distance, height difference, coordinates and REM measurement.
- It is possible to allocate softkeys in the Setting-out measurement menu to suit various applications and the
 ways that different operators handle the instrument.
 "20.6 Allocating Key Functions"

16.1 Using the Guide Light

When the guide light is set to ON, the flashing speed of the light indicates the status of the instrument and can be known when the user is located at a distance from the instrument. Also, the flashing colors relative to the target indicate the direction of the instrument and allow the user to reposition the target.

Turning the Guide light ON/OFF: "5.1 Basic Key Operation"

• The pattern of the guide light can be changed.

"20.2 Instrument Configuration"


Guide light status and meaning

Indication for positioning target during setting-out measurement

Light status	Meaning
Increased flashing speed	(From position of poleman) Move target toward instrument
Decreased flashing speed	(From position of poleman) Move target away from instrument
Fast flashing	Target is at correct distance
Red	(From position of poleman) Move target left
Green	(From position of poleman) Move target right
Red and Green	Target is at correct horizontal position


16.2 Distance Setting-out Measurement


The point is to be found based on the horizontal angle from the reference direction and the distance from the instrument station.




PROCEDURE

 Select "Setting out" in <Menu> to display <Setting out>.








- Select "Occupy setup" to display <Occupy setup>.
 Enter data for the instrument station and press [OK] to move to Backsight setup.
 - 14.1 Entering Instrument Station Data
- Set the azimuth angle for the backsight station. Press [OK] to return to <Setting out>.
 "14.2 Azimuth Angle Setting"



- 4. Select "SO data setting" In <Setting out> to display <SO data setting>. In the distance mode that conforms to your measurement requirements, enter the included angle between the reference point and the setting-out point in "SO.H.ang", and the distance (slope distance, horizontal distance or height difference) from the instrument station to the position to be set out in "SO.Sdist".
 - Each time [Shvr] is pressed, the distance mode changes from "SD" (slope distance), "HD" (horizontal distance), "VD" (height difference), and "Ht." (REM).
 - Press [COORD] in the second page and input coordinates in <Key in coord>. The angle and distance from these coordinates to the position to be set out will be calculated.
- 5. Enter values and press **[OK]** to display the screen at right.







6. Position the target on the line of sight and press [MEAS] to begin distance measurement.

The distance and direction to move the target until the setting out point is located is displayed on the instrument. The sighting point measurement results (currently installed position of the target) are displayed.

Movement indicator (Red indicates that target position is correct)

 \lhd : (Viewed from instrument) Move target to the left

 $\ \, > \quad \, : \hbox{(Viewed from instrument) Move target to the right}$

▼ : (Viewed from instrument) Move target closer


▲ : (Viewed from instrument) Move target away


▲▼ : (Viewed from instrument) Target position is correct


★ : Move target upward★ : Move target downward★ : Target position is correct


• Each time [Shvr] is pressed, the distance mode changes from horizontal distance, height difference, slope distance (REM), and slope distance.

- Press [CNFG] to set setting out accuracy. When the
 position of the target is within this range both arrows
 will be displayed to indicate that the target position is
 correct.
- Move the target until the distance to the setting-out point reads 0m. When the target is moved within the allowed range, all distance and position arrows are displayed.










 Press {ESC} to return to <Setting out>. Set the next setting out point to continue setting out measurement.

16.3 Coordinates Setting-out Measurement

After setting the coordinates for the point to be set out, the instrument calculates the setting-out horizontal angle and horizontal distance. By selecting the horizontal angle and then the horizontal distance setting-out functions, the required coordinate location can be set out.




- Previously recorded setting-out points can be placed in order. Up to 50 points can be recorded.
- To find the Z coordinate, attach the target to a pole etc. with the same target height.

PROCEDURE

to 3


 Select "Setting out" in <Menu> to display <Setting out>.



 Select "Occupy setup" to display <Occupy setup>. If necessary, enter data for Backsight setup.
 "16.2 Distance Setting-out Measurement" steps 2 Select "Key in coord" in <Setting out>. Record all the setting-out points (includes setting-out points you will measure from now).

Press [ADD] to record new data.

- Press [DEL] in the second page to delete the selected setting out point.
- Press [DELALL] in the second page to delete all setting out points.







- 4. Select a setting-out point in the first screen of step 3 and press **[OK]** to display <Set out Coords>.
- 5. Position the target on the line of sight and press [MEAS] to begin distance measurement. The distance and direction to move the target until the setting out point is located is displayed on the instrument. The sighting point measurement results (currently installed position of the target) are


displayed.

- Switch between the tabs to display different sets of information.
- The Graph 1 tab shows the current position of the mirror and the direction to the setting out point from this position.







The Graph 2 tab shows the position of the setting out point (square) and the current location of the mirror (circle).




ove the target to find the correct distance (0 is displayed) to the setting out point.

Movement indicators: "16.2 Distance Setting-out Measurement" step 6







Press [OK] to return to <Key in coord>. Set the next setting out point to continue setting out measurement.


16.4 REM Setting-out Measurement

To find a point where a target cannot be directly installed, perform REM setting-out measurement.


"13.4 REM Measurement"

PROCEDURE

- Install a target directly below or directly above the point to be found. Then use a measuring tape etc. to measure the target height (height from the survey point to the target).
- Select "Occupy setup" in <Setting out> to display <Occupy setup>. If necessary, enter data for Backsight setup.
 "16.2 Distance Setting-out Measurement" steps 2 to 3
- 3. Select "SO data setting" In <Setting out> to display <SO data setting>. Press [Shvr] until the distance input mode is "SO.Height.". Input height from the surveying point to the position to be set out in "SO.Height". If necessary, input the angle to the point to be set out.



4. Enter values and press **[OK]** in step 3 to display the screen at right.



5. Sight the target and press [MEAS]. Measurement begins and the measurement results are displayed.

Press [REM] to start REM measurement.
 The distance (height difference) and direction to move the target until the sighting point and setting out point are located is displayed on the instrument.

Press [STOP] to stop measuring.

Find the setting-out point by moving the telescope until the distance to the setting-out point reads 0m.


 Movement indicator (Red indicates that target position is correct)


: Move the telescope near the zenith
: Move the telescope near the nadir
: Telescope direction is correct


For details of other movement indicators:

"16.2 Distance Setting-out Measurement" step 6

Press [CNFG] to set setting out accuracy. When the
position of the target is within this range both arrows
will be displayed to indicate that the target position is
correct.







7. Press **(ESC)** to return to <SO data setting>.


17.OFFSET MEASUREMENT

Offset measurements are performed in order to find a point where a target cannot be installed directly or to find the distance and angle to a point which cannot be sighted.

- It is possible to find the distance and angle to a point you wish to measure (target point) by installing the target at a location (offset point) a little distance from the target point and measuring the distance and angle from the survey point to the offset point.
- The target point can be found in the three ways explained in this chapter.
- The instrument station and backsight must be set before the coordinates of an offset point can be found. Station and backsight setup can be performed in the Offset menu.
 - COCcupy setup: "14.1 Entering Instrument Station Data", Backsight setup: "14.2 Azimuth Angle Setting".
- It is possible to allocate softkeys in measurement menus to suit various applications and the ways that different operators handle the instrument.
 - "20.6 Allocating Key Functions"

17.1 Offset Single-distance Measurement


Finding it by entering the horizontal distance from the target point to the offset point.



- When the offset point is positioned to the left or right of the target point, make sure the angle formed by lines connecting the offset point to the target point and to the instrument station is almost 90°.
- When the offset point is positioned in front of or behind the target point, install the offset point on a line linking the instrument station with the target point.

PROCEDURE

- Set the offset point close to the target point and measure the distance between them, then set up a prism on the offset point.
- 2. Select "Offset" in <Menu> to display.



Select "Occupy setup" to display <Occupy setup>.
 Enter data for the instrument station and press [OK] to move to Backsight setup.

14.1 Entering Instrument Station Data

4. Set the azimuth angle for the backsight station. Press **[OK]** to return to <Offset>.

"14.2 Azimuth Angle Setting"

5. Select "OffsetDIST".

Input the following items.


- (1) Direction of the offset point.
- (2) Horizontal distance from the target point to the offset point.
- · Direction of offset point


← : On the left of the target point.


→ : On the right of the target point.

↓ : Closer than the target point.

↑ : Beyond the target point.








6. Sight the offset point and press **[MEAS]** in the screen of step 5 to start measurement.

Press [STOP] to stop the measurement. The measurement results are displayed.

 Press [HVD/nez] to switch results for the target point between distance/angle values and coordinate/ elevation values. Results for target point




Results for offset point

17.2 Offset Angle Measurement


Sighting the direction of the target point to find it from the included angle.

Install offset points for the target point on the right and left sides of and as close as possible to the target point and measure the distance to the offset points and the horizontal angle of the target point.




PROCEDURE

- Set the offset points close to the target point (making sure the distance from the instrument station to the target point and the height of the offset points and the target point are the same), then use the offset points as the target.
- Select "Offset" in <Menu> to display <Offset>.Select "OffsetANG.".




3. Sight the offset point and press **[MEAS]** to start measurement.

Press [STOP] to stop the measurement.



- 4. Sight the target point and press [H.ANG].
 - Press [HVD/nez] to switch results for the target point between distance/angle values and coordinate/ elevation values.

Results for target point



Results for offset point

5. Press **[OK]** in the screen in step 4 to return to <Offset>.


17.3 Offset Two-distance Measurement

By measuring the distances between the target point and the two offset points.


Install two offset points (1st target and 2nd target) on a straight line from the target point, observe the 1st target and 2nd target, then enter the distance between the 2nd target and the target point to find the target point.

• It is possible to make this measurement easily using the optional equipment: the 2-point target (2RT500-K). When using this 2-point target, be sure to set prism constant to 0.

1. **T* "24. TARGET SYSTEM"



How to use 2-point target (2RT500-K)




- Install the 2-point target with its tip at the target point.
- · Face the targets toward the instrument.
- · Measure the distance from the target point to the 2nd target.
- Set the prism constant to 0mm.


PROCEDURE

Select "5.Offset2D".

- 1. Install two offset points (1st target, 2nd target) on a straight line from the target point and use the offset points as the target.
- 2. Select "Offset" in <Menu> to display <Offset>.



- 3. Press [CNFG] and input the distance from the 2nd target to the target point in "Offset dist.". Set reflector settings and press [OK] to confirm.
 - Press [LIST] to edit the prism constant and aperture in <Reflector setting>.




4. Sight the 1st target and press **[MEAS]** to start measurement.

Press **[STOP]** to stop the measurement. The measurement results are displayed. Press **[YES]** to confirm.




5. Sight the 2nd target and press **[MEAS]** to start measurement.

Press **[STOP]** to stop the measurement. The measurement results are displayed.



6. Press **[YES]** to display results for the target point.


Press **[HVD/nez]** to switch results for the target point between distance/angle values and coordinate/ elevation values.



18.MISSING LINE MEASUREMENT

Missing line measurement is used to measure the slope distance, horizontal distance, and horizontal angle to a target from the target which is the reference (starting point) without moving the instrument.

- It is possible to change the last measured point to the next starting position.
- Measurement results can be displayed as the gradient between two points.




 It is possible to allocate softkeys in measurement menus to suit various applications and the ways that different operators handle the instrument.
 "20.6 Allocating Key Functions"

18.1 Measuring the Distance between 2 or more Points

PROCEDURE

1. Select "MLM" in <Menu>.





2. Sight the starting position, and press [MEAS] to start measurement.

Press [STOP] to stop measurement.




 When measurement data already exists the screen of step 3 is displayed and measurement starts.





- Sight the next target and press [MLM] to begin observation. Slope distance, grade, horizontal distance and height difference between multiple points and the starting position can be measured this way.
 - Press [MEAS] to re-observe the starting position. Sight the starting position and press [MEAS].
 - When [MOVE] is pressed, the last target measured becomes the new starting position to perform missing line measurement of the next target.
 "18.2 Changing the Starting Point"

Results for measurement between starting position and second target




Results for current point

4. Press **{ESC}** or tap the cross in the top-right corner to end missing line measurement.


18.2 Changing the Starting Point

It is possible to change the last measured point to the next starting position.




PROCEDURE

- 1. Observe the starting position and target following steps 1 to 3 in "18.1 Measuring the Distance between 2 or more Points".
- 2. After measuring the targets, press [MOVE].



Press [YES] in the confirmation message window.

• Press [NO] to cancel measurement.



- 3. The last target measured is changed to the new starting position.
- 4. Perform missing line measurement following steps 3 to 4 in "18.1 Measuring the Distance between 2 or more Points".

19.SURFACE AREA CALCULATION

You can calculate the area of land (slope area and horizontal area) enclosed by three or more known points on a line by inputting the coordinates of the points

Input
Coordinates:
P1 (N1, E1, Z1)
Surface area:
S (horizontal area and slope area)

...
P5 (N5, E5, Z5)

N

P2

P3

P3

- Number of specified coordinate points: 3 or more, 30 or less
- Surface area is calculated by observing in order the points on a line enclosing an area.
- It is possible to allocate softkeys in measurement menus to suit various applications and the ways that different operators handle the instrument.

P5

**E7 "20.6 Allocating Key Functions"

0



- An error will occur if only two points (or less) are entered when specifying an enclosed area.
- Be sure to observe points on an enclosed area in a clockwise or counterclockwise direction. For example, the area specified by entering point numbers 1, 2, 3, 4, 5 or 5, 4, 3, 2, 1 implies the same shape. However, if points are not entered in numerical order, the surface area will not be calculated correctly.




Slope area

The first three points specified (measured) are used to create the surface of the slope area. Subsequent points are projected vertically onto this surface and the slope area calculated.


PROCEDURE Surface area calculation by measuring points


1. Select "Area calc." in <Menu>




- E


 Press [OBS] to display <Area calculation/ measurement>. Sight the first point on the line enclosing the area, and press [MEAS].
 Measurement begins and the measured values are displayed. Press [STOP] to stop measuring.






3. The measurement results are displayed. Press **[YES]** to confirm. The value of point 1 is set in "Pt 01".







4. Repeat steps 2 to 3 until all points have been measured. Points on an enclosed area are observed in a clockwise or counterclockwise direction. For example, the area specified by entering point numbers 1, 2, 3, 4, 5 or 5, 4, 3, 2, 1 implies the same shape.



5. Press **[CALC]** to display the calculated area.






6. Press [OK] to return to <Area/key in coord.>.

20.CHANGING THE SETTINGS

This section explains the contents of parameter settings in Basic mode and how to change these settings. Each item can be changed to meet your measurement requirements.


<Configuration> can be accessed by pressing the "CONFIG" icon in <Top>.



The following chapters provide details of items in Configuration mode.

- Communication settings 10. CONNECTING TO EXTERNAL DEVICES
- Instrument configurations 🕼 "22.2 Tilt Sensor", "22.3 Collimation"

20.1 Observation Conditions



Items set and options (*: Factory setting)

Distance mode: Sdist (slope distance)*/Hdist (horizontal distance)/V.dist (height

difference) Ground*/Grid

Hdist : Ground*/Grid

Tilt crn (tilt correction) : Yes (H,V)*/No, Yes (V)

Tilt error: No action*/Go to <Tilt> (electric circular level is displayed)

Coll.crn. (collimation correction) : No/Yes*

C&R crn.: No/Yes(K=0.142)/Yes(K=0.20)*

V manual: No*/Yes

V.obs (vertical angle display method) : Zenith*/Horiz./Horiz ±90

Coordinates: N-E-Z*/E-N-Z

Sea level crn. (Sea level correction) : Yes/No*

Ang.reso. (Angle resolution): FX-201/202: 0.5"/1"*

FX-203/205: 1"*/5"

Dist.reso. (Distance resolution) : 0.1 mm/1 mm*

Tracking reso. (Tracking resolution) : 1 mm/10 mm*


ppm setting: Press/Temp.*/+Humidity

| | Hdist

The instrument calculates horizontal distance using slope distance values. Horizontal distance display can be selected from the following methods.

Ground: The distance that reflects neither the Sea level correction factor nor the Scale factor.

Grid: The distance in the plane rectangular coordinates system that reflects the Sea level correction and Scale factors (or the distance in the plane rectangular coordinates system that reflects the Scale factor only, when "No" is set for "Sea level crn".)



Automatic tilt angle compensation mechanism


The vertical and horizontal angles are automatically compensated for small tilt errors using the 2-axis tilt sensor.

- Read the automatically compensated angles when the display has stabilized.
- The horizontal angle error (vertical axis error) fluctuates according to the vertical axis, so when the instrument is not completely leveled, changing the vertical angle by rotating the telescope will cause the displayed horizontal angle value to change.
- Compensated horizontal angle = Measured horizontal angle + Tilt in angle/tan (Vertical angle)
- When the telescope is directed close to the zenith or nadir angle, tilt compensation is not applied to the horizontal angle.

Collimation correction

The instrument has a collimation correction function that automatically corrects horizontal angle errors caused by horizontal axis and leveling axis errors. Normally set this item to "Yes".

V mode (vertical angle display method)



Sea level correction

The instrument calculates horizontal distance using slope distance values. As this horizontal distance does not take height above sea level into consideration, performing spherical correction is recommended when measuring at high altitudes. Spherical distance is calculated as follows.

Spherical distance = $\frac{R - Ha}{R} \times d_1$

Where: R = radius of the spheroid (6371.000m)

H_a = averaged elevation of the instrument point and target point

d₁ = horizontal distance

Dist.reso. (Distance resolution)

Select distance resolution of fine measurement. Distance resolution of rapid and tracking measurement will shift with this setting.

Tracking reso. (Tracking resolution)

Select distance resolution of tracking measurement and road measurement (N-prism only). Set this setting depending on the measurement purpose like measuring a moving target.

20.2 Instrument Configuration



Items set and options (*: Factory setting)

Power off (iii): No/5min./10min./15min./30min.*

Backlight (Reticle On) <a>\big(\frac{1}{2}\): 0 to 8 (1*) (Brightness level on pressing { \(\psi\)})

Backlight (Normal) : 0 to 8/Auto (Auto*)

Backlight Off (iii): No*/30sec/1min./5min./10min.

Key backlight : Off/On*

Reticle lev : 0 to 5 level (3*) EDM ALC : Free*/Hold

Guide pattern: 1* (simultaneous)/2 (alternating)
Laser-pointer off No/1min./5min.*/10min./30min.

Beep: On*/Off

Color: 1/2 (monochrome)/Auto (Auto*)

Touch panel: On (fixed)


Note

Press [PNL CAL] to display the touch panel calibration screen.
 "9.1 Configuring the Touch Panel"

Adjusting backlight brightness/turning the reticle illumination and key backlight ON/OFF

Pressing { \(\infty \) switches the brightness level of the backlight in conjunction with the ON/OFF status of the reticle illumination/key backlight.

When the instrument is powered ON the brightness level is set to "Backlight (Normal)". "Backlight (Normal)" was set to a higher brightness level than "Backlight (Reticle ON)" when the instrument was shipped but these values can be modified according to user preferences.



Note

• When "Backlight (Normal)" is set to "Auto" the instrument light sensor gauges the level of ambient brightness and automatically sets backlight brightness accordingly. Depending on ambient light conditions, performance of this function may be sub-optimal, or the display may flicker between brightness settings.

Power-saving automatic cut-off/Backlight Off

To save power, power to the instrument is automatically cut off if it is not operated for the set time. The backlight will similarly be turned off if the instrument is not operated for the selected time. However, the backlight will not be turned off when "Backlight" is set to "ON".

| EDM ALC

Set the light receiving status of the EDM. While carrying out continuous measurement, set this item according to the measurement conditions.

- When EDM ALC is set to "Free," the instrument's ALC will be automatically adjusted if an error occurs
 as a result of the amount of light received. Set to "Free" when the target is moved during measurement
 or different targets are used.
- When "Hold" is set, the amount of light received will not be adjusted until continuous measurement is completed.
- If an obstacle intermittently obstructs the light beam during continuous measurement and the "Signal off" error occurs, each time the obstruction occurs it takes some time for the amount of light received to be adjusted and the measurement value displayed. Set to "Hold" when the light beam used for measurement is stable but is frequently obstructed by obstacles such as people, cars, or tree branches etc. preventing measurement from being performed.

Note

 When the distance measurement mode is set to "Tracking" (target is moved during distance measurement) the EDM ALC will be adjusted regardless of the EDM ALC setting.

Laser-pointer off


To save power, the laser-pointer is automatically turned off after the set time has elapsed.

Key backlight

The key backlight can be set to "ON" or "OFF". When "key backlight" is set to "ON", the key backlight is lit /OFF in conjunction with pressing { & }.

20.3 EDM Settings

• "EDM" tab



Items set, options, and input range (*: Factory setting)

Dist. mode (Distance measurement mode): Fine 'R'*/Fine AVG n= 1(Setting: 1 to 9 times)/Fine 'S'/Rapid 'R'/

Rapid 'S'/Tracking/Road

Reflector: Prism*/Sheet/N-Prism

Prism constant: -99 to 99 mm ("Prism" is selected: 0*, "Sheet" is selected: 0)

(When Dist.reso. is 1 mm)

Illum. hold ({ 🌣 } function): Laser-pointer*/Guide light

Guide light (Brightness): 1 to 3 (3*)

- The setting for "Fine AVG" distance measurement mode can be increased/decreased using the [+]/[] softkeys.
- "Road" in "Dist. mode" is displayed only when "N-Prism" is selected in <Reflector>.

F" PROCEDURE Recording and editing target information"

- Target information can be edited and recorded.
 - "PROCEDURE Recording and editing target information"
- "Prism constant" will not be displayed when "N-Prism" is selected in "Reflector".
- When 0.1mm is selected in "Dist.reso", "Prism constant value" can be input to the first decimal place.

 "20.1 Observation Conditions"
- When "prism constant" values are changed and **[OK]** is pressed, these changes are reflected in the status bar/Starkey mode target type display temporarily. This display will also change to reflect changes in target information settings made using a data collector temporarily. In both of the above cases, changes will not be recorded in <Reflector setting>.

Status bar: "5.2 Display Functions", Starkey mode: "5.4 Starkey Mode", <Reflector setting>:

- "PROCEDURE Recording and editing target information", Cold boot: "9.2 Resolving Software Issues Cold boot"
- The Guide light brightness item ("Guide light (Brightness)") will be displayed only when "Illum. hold" is set to "Guide light".

Road

"Road" is the specialized distance mode to measure road surface etc. by sighting obliquely and to obtain rough measurement values. "Road" can be selected only when "Reflector" is set to "N-Prism". Even if "Road" is selected, "Distance mode" changes to "Tracking" automatically when "Reflector" is set to other than "N-Prism".


Prism constant correction

Reflective prisms each have their prism constant.

Set the prism constant correction value of the reflective prism you are using. The prism constant correction value is a value that the prism constant is inverted to positive or negative. (E.g. if the prism constant is 40 mm, the correction value turns to -40 mm.)

When selecting "N-Prism" in "Reflector", prism constant correction value is set to "0" automatically.

"ppm" tab



- [Oppm]: Atmospheric correction factor returns to 0 and temperature and air pressure are set to the factory settings.
- · Atmospheric correction factor is calculated and set using the entered values of the temperature and air pressure. Atmospheric correction factor can also be entered directly.
- When the settings here are different between basic mode and program mode, program mode settings are prior for use.

Items set, options, and input range (*: Factory setting)

Temperature: -30 to 60°C (15*)/-22 to +140°F (59*) (When Dist.reso. is 1 mm) Pressure: 500 to 1400hPa (1013*)/375 to 1050mmHg (760*)/ 14.8 to 41.3

(inchHg) (29.9*) (When Dist.reso. is 1 mm)

0 to 100% (50*) (When Dist.reso. is 1 mm) Humidity: ppm (Atmospheric correction factor): -499 to 499 (0*) (When Dist.reso. is 1 mm)

- The "Humidity" item is displayed only when the "ppm setting" in "Obs. condition" is set to "+Humidity".
- When 0.1 mm is selected in "Dist.reso", values can be input to the first decimal place.

Atmospheric correction factor

The velocity of the light beam used for measurement varies according atmospheric conditions such as temperature and air pressure. Set the atmospheric correction factor when you wish to take this influence into account when measuring.

- The instrument is designed so that the correction factor is 0 ppm at an air pressure of 1013.25 hPa, a temperature of 15°C, and a humidity of 50%.
- By inputting the temperature, air pressure values and humidity, the atmospheric correction value is calculated using the following formula and set into the memory.

Atmospheric Correction Factor (ppm) =
$$282.324 - \frac{0.294280 \times p}{1 + 0.003661 \times t} + \frac{0.04126 \times e}{1 + 0.003661 \times t}$$

t : Air temperature (°C)

p : Pressure (hPa)

e: Water vapor pressure (hPa)

h: Relative humidity (%)

E: Saturated water vapor pressure

• e (water vapor pressure) can be calculated using the following formula.

$$e = h \times \frac{E}{100}$$
 $E = 6.11 \times 10^{(t + 237.3)}$


- The instrument measures the distance with a beam of light, but the velocity of this light varies according to the index of refraction of light in the atmosphere. This index of refraction varies according to the temperature and pressure. Near normal temperature and pressure conditions:
 With constant pressure, a temperature change of 1°C: an index change of 1 ppm.
 With constant temperature, a pressure change of 3.6 hPa: an index change of 1 ppm.
 To perform high accuracy measurements, it is necessary to find the atmospheric correction factor from even more accurate temperature and pressure measurements and perform an atmospheric correction. It is recommended that extremely precise instruments be used to monitor the air temperature and pressure.
- Enter the average temperature, air pressure and humidity along the measurement beam route in "Temperature", "Pressure" and "Humidity".

 Flat terrain:Use the temperature, pressure and humidity at the midpoint of the line.

 Mountainous terrain:Use the temperature, pressure and humidity at the intermediate point (C).

If it is not possible to measure the temperature, pressure and humidity at the midpoint, take such measurements at the instrument station (A) and the target station (B), then calculate the average value.


Average air temperature: (t1 + t2)/2 Average air pressure: (p1 + p2)/2 Average humidity: (h1 + h2)/2




• If the weather correction is not required, set the ppm value to 0.

PROCEDURE Recording and editing target information

The **[LIST]** softkey is displayed when either "Reflector" or "Prism const." is selected in the "EDM" tab of <EDM configurations>.



- 1. Press [LIST] to display a list of all recorded targets.
 - [ADD]: Displays <Reflector list>. Select the desired target from this list and press [OK] to register in the list in <Reflector setting>. Up to a maximum of 6 targets can be recorded.
 - [DEL]: Deletes the selected target.



2. To edit a target, select the desired target and press **[EDIT]**. <Reflector/edit> is displayed. Select/input relevant information for the target.

Reflector: Prism/Sheet/N-Prism

Const.: -99 to 99 mm (When Dist.reso. is 1 mm)

 When selecting "N-Prism" in "Reflector", prism constant correction values are set to "0" automatically.



 Press [OK] in the screen of step 2 to save edited information and return to <Reflector setting>.
 Press [OK] to return to <EDM configurations>.

20.4 Allocating User-defined Tabs

It is possible to allocate tabs in Observation mode and Menu mode to suit the measurement conditions. It is possible to operate the instrument efficiently because unique tab allocations can be preset to suit various applications and the ways that different operators handle the instrument.

- The current tab allocations are retained until they are revised again, even when the power is cut off.
- Press [CLEAR] in <Customize/Select screen> to return all customized configurations including screen controls, status bar/Starkey mode settings, and softkey allocations to their previous settings.
- One screen can contain a maximum of 5 tabs.



• When tab allocations are recorded and registered, the previously recorded tab settings are cleared.

Tab allocations

The following are tabs allocated when the instrument was shipped and tabs that can be defined by the user.

"Basic observation"

Factory settings	User-definable tabs
SHV	SHV
SHVdist	SHVdist
Graphic	SHV + Coord.

Setting out

Factory settings	User-definable tabs
Obs.	Obs.
Graphic	

Setting out Coord.

Factory settings	User-definable tabs
SHV	SHV
NEZ	NEZ
Graph1	
Graph2	




• Graphic tab cannot be deleted.


PROCEDURE Allocating tabs

1. Select "Customize" to display <Customize/Select screen>.

Select the measurement mode in which you want to allocate a tab.




Select "Tab page"




- 2. Use the softkeys (**[ADD]**, **[DEL]** etc.) in <Customize tab page> to allocate the desired tab page layout.
 - Press [ADD] to add the selected tab at the righthand side of the screen.
 - Press **[INS]** in the second page to insert the selected tab in front of the current tab.
 - Press **[CNFG]** in the second page to replace the current tab with the selected tab.
 - Press [DEL] to delete the current tab.



• Tabs, once deleted, cannot be retrieved.



Select a tab type from the "Type" drop-down list.



- 3. Repeat step 2 to perform further tab allocations.
- 4. Press **{ESC}** to finish allocating tabs. The allocated tabs are stored in memory and <Customize> is displayed. The newly allocated tabs appear in the relevant measurement screen.

20.5 Customizing Screen Controls

It is possible to customize screen controls in Observation mode to suit the measurement conditions and the different methods employed by different operators.

- The current screen control settings are retained until they are revised again, even when the power is cut off.
- Press [CLEAR] in <Customize/Select screen> to return all customized configurations including tab pages, status bar/Starkey mode settings, and softkey allocations to their previous settings.
- Screen controls cannot be set for the "Graphic" tab.




· When screen control settings are recorded and registered, the previously recorded settings are cleared.

PROCEDURE Customizing screen controls

1. Select "Customize" to display <Customize/Select screen>.

Select the measurement mode in which you want to customize screen controls.





Select "Control".


2. Press [ADD] to add a control drop-down list.Press [DEL] to delete the selected control.





· Controls, once deleted, cannot be retrieved.


















20.6 Allocating Key Functions

It is possible to allocate the softkeys in Observation mode to suit the measurement conditions. It is possible to operate the instrument efficiently because unique softkey allocations can be preset to suit various applications and the ways that different operators handle the instrument.

- The current softkey allocations are retained until they are revised again, even when the instrument is powered OFF.
- Press [CLEAR] in <Customize/Select screen> to return all customized configurations including tab pages, status bar/Starkey mode settings, and screen controls to their previous settings.

#

- When softkey allocations are recorded and registered, the previously recorded key settings are cleared.
- Softkeys cannot be allocated to "Graphic" tabs.

The following are the screens that can be customized and softkey allocations when the FX was shipped.

1. "SHV" and "SHVdist" tabs of <Basic observation>

Page 1 [EDM] [TILT] [0SET] [MEAS]

Page 2 [MENU] [OFFSET] [H-SET] [COORD]

Page 3 [MLM] [RESEC] [REM] [S-O]

2. "Obs." tab of <Setting out>

Page 1 [REM] [SHVR] [CNFG] [MEAS]

Page 2 [---][---][---] Page 3 [---][---][---]

3. "SHV" and "NEZ" tabs of <Set out Coords>

Page 1 [OK] [---][CNFG] [MEAS]
Page 2 [---] [---] [---]
Page 3 [---] [---] [---]

The following functions can be allocated to the softkeys.

[---] : No functions set

[MEAS] : Distance and angle measurement

[CNFG] : Set setting out accuracy (can only be allocated to 2 and 3 above)

[SHV] : Switch the "SHV" tab and "SHVdist" tab (can only be allocated to 1 above)

[SHVR] : Switch distance mode between slope distance (SD)/horizontal distance (HD)/height difference

 $(VD)/REM\ (R)\ in\ setting\ out\ screens.\ The\ capitalized\ letter\ in\ the\ softkey\ indicates\ the\ currently$

selected mode (can only be allocated to 2 above).

[OK] : Terminate setting out measurement for the selected setting out point and return to <Key in

coord>. This setting out point will be removed from the list (can only be allocated to 3 above).

[0SET] : Set horizontal angle to 0° [H-SET] : Set required horizontal angle

[R/L] : Select horizontal angle right/left. The capitalized letter in the softkey indicates the currently

selected mode.

[ZA / %] : Switch between zenith angle/slope in %. The capitalized letter in the softkey indicates the

currently selected mode.

[HOLD] : Hold horizontal angle/release horizontal angle

[CALL] : Display final measurement data

[HVOUT-S] : Output angle measurement results to an external device (SET format)

[HVDOUT-S]: Output distance and angle measurement results to an external device (SET format)

[NEZOUT-S]: Output coordinates data to an external device (SET format)

[HVOUT-T] : Output angle measurement results to an external device (GTS format) (can only be allocated

to 1 above)

[HVDOUT-T]: Output distance and angle measurement results to an external device (GTS format) (can only

be allocated to 1 above)

[NEZOUT-T]: Output coordinates data to an external device (GTS format) (can only be allocated to 1 above)

[F/M] : Switch distance units between meters/feet

[HT] : Set the instrument station, coordinates and instrument height

[S-LEV] : Return signal [TILT] : Display tilt angle [EDM] : EDM settings

[MENU] : Display <Menu> (coordinate measurement, setting out measurement, offset measurement,


REM measurement, missing line measurement, resection, area calculation)

[COORD] : Coordinates measurement : Setting-out measurement [S-O] [OFFSET] : Offset measurement : Angle offset measurement [A-OFS] : Distance offset measurement [D-OFS] [2D-OFS] : Offset/2D measurement [MLM] : Missing line measurement : REM measurement [REM] [RESEC] : Resection measurement : Surface area measurement [AREA]


PROCEDURE Allocating a softkey

1. Select "Customize" to display <Customize/Select screen>.


Select the measurement mode in which you want to allocate a softkey.




Select "Softkey".



2. Select the desired tab. All softkeys currently allocated to each page of that tab are displayed.



 Select the softkey whose allocation you want to change. Tapping a softkey, or pressing {SPACE} when the cursor is aligned with a softkey, will display <Softkey list>.



- 4. Select the desired softkey from <Softkey list> to allocate to the position specified in step 3.
- 5. Repeat steps 3 to 4 to perform further key allocations.
- 6. Press **[OK]** to finish allocating keys. The allocated keys are stored in memory and <Customize> is displayed. The newly allocated keys appear in the relevant measurement screen.

20.7 Changing Starkey Mode Icons

It is possible to preset icon allocations of the Starkey mode to suit various applications and the ways that different operators handle the instrument.

- The current icon allocations are retained until they are revised again, even when the power is turned off.
- Press [CLEAR] in <Customize/Select screen> to return all customized configurations including tab pages, screen controls and softkey allocations to their previous settings.




- When icon allocations are recorded and registered, the previously recorded settings are cleared.
- When icon allocations are recorded and registered, the setting reflects to status bar.
- The following icons can be allocated to the status bar:

Remaining battery power
Target display
Guide light/Laser-pointer
Tilt angle compensation
Communication status
Input mode
SIP (Input panel)
ppm (atmospheric correction factor)
Touch panel
Disk
No icon


PROCEDURE Changing icon allocations

1. Select "Customize" to display <Customize/Select screen>.

Select "Starkey mode"




2. Select the icon (in the Starkey mode) you wish to reallocate. Tap the icon to display <Starkey list>.




3. Select the new icon from <Starkey list>.

The icon is allocated in the selected icon position.



- 4. Repeat steps 2 to 3 to perform further icon allocations.
- Press {ENT} to finish allocating icons. The allocated icons are stored in memory and <Customize/Select screen> is restored. The newly allocated icons appear in the Starkey mode.

20.8 Unit



Items set and options (*: Factory setting)

Temperature: Celsius*/Fahrenheit Pressure: hPa*/mmHg/InchHg


Angle: Degree (DDD.MMSS)*/Gon/Mil

Distance: Meter*/Feet/Inch

Feet (only displayed when "Feet" or "Inch" selected above): International*/US

Inch (Fraction of an inch)

"Fraction of an inch" is the unit used in the United States and expressed like the following example.



- ① 10.000 feet
- 2 0.875 feet x 12=10.5 inch
- ③ 0.5 inch=1/2 inch



• Even if "inch" is selected in this setting, all the data including the result of area calculation are output in "feet" and all the distance values must be input in "feet". In addition, when the "inch" display exceeds the range, it is displayed in "feet".

20.9 Changing Password

When a password has been set, the password screen will appear when the instrument is powered ON. Setting a password allows you to protect important information such as measurement data.

No password was set when the instrument is shipped. When setting a password for the first time, leave the "Old password" box blank.



Items set

Old password:

New password:

New password again:

Input current password

Input the new password


Input the new password again

- Password can be up to 16 characters in length. Input characters will be displayed as asterisks.
- To deactivate the password function, perform the new password setting procedure but enter a "space" in the "New password" box.



• The password function will not be canceled when a cold boot is performed.

20.10 Date and Time



Items set

Date: Manually input date or select from the drop-down calendar by tapping ∇ .

Time: Manually input time or set using [A]/[V].

Pressing **(SPACE)** will increment the selected section by 1.

Date and Time

The instrument includes a clock/calendar function.

20.11 Restoring Default Settings

Perform a cold boot to return all items to factory settings. A cold boot will not erase surveying data in instrument. However, if the data in the memory is important, **BE SURE TO TRANSFER IT TO A PERSONAL COMPUTER BEFORE PERFORMING A COLD BOOT.**

"To perform a cold boot, while holding $\{\mbox{$\sline{\beta}$}\}\$, and $\{\mbox{S.P.}\}\$, press $\{\mbox{$\cline{\chi}$}\}\$.

"All Settings will be cleared. Are you sure?"

Press [YES] to continue. Press {ESC} to cancel.

After **[YES]** is pressed the instrument powers ON and the screen for configuring the touch panel is displayed. Configure the touch panel to continue.

"9.1 Configuring the Touch Panel"



• The password function will not be canceled.

21.WARNING AND ERROR MESSAGES

The following is a list of the error messages displayed by the instrument and the meaning of each message. If the same error message is repeated or if any message not shown below appears, the instrument has malfunctioned. Contact your local dealer.

Backup battery dead. Clock display may no longer be correct.

The voltage supplied by the lithium battery either declines or is completely discharged. Ask your local dealer to replace the battery for you.

Bad condition

The air is shimmering a lot, etc., measuring conditions are poor.

The center of the target cannot be sighted.

Resight the target.

Unsuitable distance measurement conditions when reflectorless measurement is set. When reflectorless measurement is set, distance cannot be measured because the laser beam is striking at least two surfaces at the same time.

Choose a single surface target for distance measurement.

Precautions for setting prism: "11. FOCUSSING AND TARGET SIGHTINGS"

Calculation error

Coordinates identical to the known point coordinates observed during resection exist. Set another known point so that the known point coordinates do not coincide.

During surface area calculation, conditions necessary for calculations are not met. Check conditions and try again.

An error occurred during calculation.

Error: Read Build Info. Error: Read sysflg Error: Self check

Error: Read FX Parameter

Error: Write sysflg

Press [OK] to cancel the message. If this error message appears frequently, contact your local dealer.

Incorrect password.

Input password does not match set password. Input correct password.

Input over 3 letters!

The input password consists of less than 3 characters. Input a password at least 3 characters in length.

Need base pt. obs

During REM measurement, the observation of the target was not completed normally.

Reset and sight the prism and perform measurement again.

New password Diff.

During new password setting, the passwords input twice are different. Input new password twice correctly.

No solution

The calculation of the instrument station coordinates during resection does not converge.

Access the results and if necessary, perform the observations again.

Out of range

During gradient % display, the display range (less than ± 1000%) has been exceeded.

During REM measurement, either the vertical angle has exceeded horizontal ±89° or the measured distance is greater than 9999.999m.

Install the instrument station far from the target.

The instrument station coordinates calculated during resection are too high.

Perform the observation again.

During area calculation, results exceeded the display range.

Signal off

The reflected light is not observed when distance measurement begins. Or, during measurement, the reflected light has weakened or is blocked.

Either sight the target again or, when using a reflective prism, increase the number of reflective prisms.

Take BS reading

The origin measurement is not finished normally in missing line measurement. Collimate the origin accurately and measure it again.

Target not found !!

The prism cannot be found within the Search area range.

Reset and sight the prism and perform measurement again.

Temp Rnge OUT

The instrument is outside useable temperature range and accurate measurement cannot be performed. Repeat measurement within the appropriate temperature range.

Tilt over range!!

The tilt angle exceeds the tilt angle compensation range of the sensor.

Level the instrument again.

Time out !!

Measurement is not carried out in the allotted time.

Reset and sight the prism and perform measurement again.

22.CHECKS AND ADJUSTMENTS

FX is a precision instrument that requires fine adjustments. It must be inspected and adjusted before use so that it always performs accurate measurements.

- Always perform checking and adjustment in the proper sequence beginning from "22.1 Circular Level" to "22.6 Additive Distance Constant".
- In addition, the instrument should be inspected with special care after it has been stored a long time, transported, or when it may have been damaged by a strong shock.
- Make sure the instrument is securely set up and stable before performing checks and adjustments.

22.1 Circular Level

The bubble tube is made of glass, so it is sensitive to temperature changes or to shock. Check and adjust it as outlined below.



• Be careful that the tightening tension is identical for all the adjusting screws. Also, do not over-tighten the adjusting screws as this may damage the circular level.

PROCEDURE Checking and adjusting



Tap Tilt angle compensation icon in the Status icon or in Starkey mode to display electric circular level.




• If the tilt sensor is misaligned, the circular level is not adjusted correctly.


"22.2 Tilt Sensor"

2. Check the position of the bubble of the circular level. If the bubble is not off-center, no adjustment is necessary.

If the bubble is off-center, perform the following adjustment.

First confirm the off-center direction.
 Use the adjusting pin to loosen the circular level adjustment screw on the side opposite in the direction the bubble is displaced to move the bubble to the center.





Circular level

4. Adjust the adjusting screws until the tightening tension of the three screws is the same to align the bubble in the middle of the circle.


22.2 Tilt Sensor

If the tilt angle shown on the display shifts from tilt angle 0° (zero point), the instrument is not correctly levelled. This will adversely affect angle measurement.


Perform the following procedures to cancel the tilt zero point error.

PROCEDURE Checking and adjusting


- 1. Carefully level the instrument. If necessary, repeat the procedures to check and adjust the bubble levels.
- 2. Select "Inst. cons." in <Configuration>



3. Select "Tilt offset".



4. Level the instrument until the X/Y tilt angles are ±1'. Wait a few seconds for the display to stabilize, then read the current tilt angle in the X (sighting) direction and Y (horizontal axis) direction.



- 5. Press **[OK]** and rotate the top of the instrument and telescope 180° from the current position.
- Wait a few seconds for the screen to stabilize, then read the automatically compensated angles X2 and Y2.

7. In this state, calculate the following offset values (tilt zero point error).

Xoffset = (X1+X2)/2 Yoffset = (Y1+Y2)/2

If one of the offset values (Xoffset, Yoffset) exceeds ± 10 ", adjust the value using the following procedure. When the offset value falls within the range ± 10 ", adjustment is not necessary.

Press **{ESC}** to return to <Instrument constants>.

- Tilt offset/Obs.

 Take F2

 Tilt X

 -1'00"

 Tilt Y

 0'23"

 ZA

 477

 0'23"

 ZA

 270°31'50"


 HA-R

 286°44'56"

 OK
- 8. Press **[OK]** and rotate the top of the instrument and telescope through 180°.
- Confirm that the values are in the adjustment range.
 If both correction constants are within the range the current value ±1', select [YES] to renew the correction angle. <Instrument constants> is restored. Continue to step 11.

If the values exceed the adjustment range, select **[NO]** to cancel the adjustment and return to the screen in step 4. Contact your local dealer to perform the adjustment.

Results for target point



Results for offset point

PROCEDURE Rechecking

10.Select "Tilt offset".

- 11. Wait a few seconds for the display to stabilize, then read the automatically compensated angles X3 and Y3.
- 12.Press **[OK]** and rotate the top of the instrument and telescope through 180°.
- 13. Wait a few seconds for the display to stabilize, then read the automatically compensated angles X4 and Y4.
- 14.In this state, the following offset values (tilt zero point error) are calculated.

Xoffset = (X3+X4)/2

Yoffset = (Y3+Y4)/2

When both offset values fall within the range ±10", adjustment is completed.

Press **{ESC}** to return to <Instrument constants>.

If one of the offset values (Xoffset, Yoffset) exceeds ±10", repeat the check and adjustment procedures from the beginning. If the difference continues to exceed ±10" after repeating the check 2 or 3 times, have your local dealer perform the adjustment.

22.3 Collimation

With this option you can measure collimation error in your instrument so that the instrument can correct subsequent single face observations. To measure the error, make angular observations using both faces.




• Perform adjustment in weak sunlight and no scintillation.

PROCEDURE Adjusting


- 1. Carefully level the instrument.
- 2. Install a target at a point about 100m in the horizontal direction from the instrument.




- 3. Select "Inst. cons." in <Configuration>.
- 4. Select "Collimation".




5. While the telescope is in Face 1, sight the center of the target correctly and press **[OK]**. Rotate the instrument 180°.



6. While the telescope is in Face 2, sight the center of the target correctly and press **[OK]**.



- 7. Press [YES] to set the constant.
 - Press **[NO]** to discard the data and return to the screen in step 5.



22.4 Reticle

With this option you can check the perpendicularity of the reticle and the horizontal/vertical positions of reticle lines.




· Check the telescope reticle by sighting the target.

PROCEDURE Check 1: Perpendicularity of the reticle to the horizontal axis

- 1. Carefully level the instrument.
- 2. Align a clearly visible target (the edge of a roof for example) on point A of the reticle line.
- 3. Use the fine motion screws to align the target to point B on a vertical line.

 If the target moves parallel to the vertical line, adjustment is unnecessary. If its movement deviates from the vertical line, have our service representative adjust it.



PROCEDURE Check 2: Vertical and horizontal reticle line positions



- Perform check in weak sunlight and no scintillation.
- "Tilt crn" should be set to "Yes (H,V)" and "Coll.crn" to "Yes" in <Obs. condition> while performing checks.

 "20.1 Observation Conditions"
- 1. Carefully level the instrument.
- 2. Install a target at a point about 100m in the horizontal direction from the instrument.



 While the Observation mode screen is displayed and the telescope is in Face 1, sight the center of the target correctly and read out the horizontal angle A1 and the vertical angle B1.

Example:

Horizontal angle A1 = 18° 34' 00" Vertical angle B1 = 90° 30' 20"

4. While the telescope is in Face 2, sight the center of the target correctly and read out the horizontal angle A2 and the vertical angle B2.

Example:

Horizontal angle A2 = 198° 34' 20" Vertical angle B2 = 269° 30' 00"

5. Do the calculations: A2-A1 and B2+B1 If A2-A1 is within 180°±20″and B2+B1 is within 360°±20″, adjustment is unnecessary.

Example: A2-A1 (Horizontal angle)

=198° 34' 20"- 18° 34' 00"

=180° 00' 20"

B2+B1 (Vertical angle)

=269° 30' 00" + 90° 30' 20"

=360° 00' 20"

If the difference is large even after repeating the check 2 or 3 times, make sure that checking and adjusting of "22.2 Tilt Sensor" and "22.3 Collimation" are completed.

If the results remain the same, have our service representative perform the adjustment.


22.5 Optical Plummet



- Be careful that the tightening tension is identical for all the adjusting screws.
- Also, do not over-tighten the adjusting screws as this may damage the circular level.


PROCEDURE Checking

- 1. Carefully level the FX and center a survey point precisely in the reticle of the optical plummet.
- Turn the upper part through 180° and check the
 position of the survey point in the reticle.
 If the surveying point is still centered, no adjustment is
 necessary.
 If the survey point is no longer centered in the optical
 plummet, perform the following adjustment.



PROCEDURE Adjusting

3. Correct half the deviation with the levelling foot screw.



1 (2)

- 4. Remove the optical plummet reticle cover.
- Use the 4 adjusting screws of the optical plummet to adjust the remaining half of the deviation as shown below.

When the survey point is on the lower (upper) part of the illustration:


Loosen the upper (lower) adjusting screw slightly, and tighten the

upper (lower) adjusting screw the same amount to move the survey point to a point directly under the center of the optical plummet.

(It will move to the line in the figure on the right.)

If the survey point is on the solid line (dotted line): Loosen the right (left) adjusting screw slightly and, tighten the left

(right) adjusting screw by the same amount to move the survey point to a point in the center of the optical plummet.



2(1)

Check to make sure that the survey point remains centered on the reticle even if the upper part of the instrument is rotated.

If necessary, perform the adjustment again.

7. Replace the optical plummet reticle cover.

22.6 Additive Distance Constant

The additive distance constant K of the FX is adjusted to 0 before delivery. Although it almost never deviates, use a baseline with a known distance precision to check that the additive distance constant K is close to 0 several times a year and whenever the values measured by the instrument begin to deviate by a consistent amount. Perform these checks as follows.



- Errors in setting up the instrument and reflective prism or in sighting the target will influence the additive distance constant. Be extremely careful to prevent such errors when performing these procedures.
- Set up so that the instrument height and the target height are identical. If a flat place is not available, use an automatic level to make sure the heights are identical.


PROCEDURE Checking

1. Find an area of flat ground where two points 100m apart can be selected.

Set up the Instrument at point A and the reflective prism at point B. Establish a point C half way between points A and B.



- 2. Precisely measure the horizontal distance between point A and point B 10 times and calculate the average value.
- Place the FX at point C directly between points A and B and set up the reflective prism at point A.



- Precisely measure the horizontal distances CA and CB 10 times each and calculate the average value for each distance.
- Calculate the additive distance constant K as follows. K = AB - (CA+CB)
- Repeat steps 1 to 5 two or three times.
 If the additive distance constant K is within ±3mm even once, adjustment is unnecessary.
 If it always exceeds this range, have our service representative perform an adjustment.

22.7 Laser Plummet (Optional Accessory)

Checks and adjustments are performed using an adjustment target. Make an enlarged or reduced copy of it.

PROCEDURE Checking

 Level the instrument and emit the laser plummet beam.


☐ "8.2 Levelling"

- 2. Rotate the upper part horizontally and place a target so that it is aligned with the center of the circle created by the rotating laser plummet beam.
 - Laser beam remains centered on the center of the target – No adjustment necessary
 - Laser beam strays from the center of the target Adjustment necessary.
 - Laser beam draws a circle outside the target circle Contact your local dealer.



PROCEDURE Adjusting

1. Turn the laser plummet adjustment cap anticlockwise and remove.




- 2. Emit the laser plummet beam.
- 3. Note the current position (x) of the laser beam.
- 4. Turn the upper part of the instrument horizontally through 180° and note the new position (y) of the laser beam.
 - Adjustment will bring the laser beam to a point midway along a line drawn between these two positions.
- 5. Check the position of the desired final position. Place a target so that its center is aligned with the desired final position.


The remaining deviation will be adjusted using the 4 fine adjustment screws.




- Be extremely careful to adjust all the fine adjustment screws by the same amount so that none will be over-tightened.
- Turn screws clockwise to tighten.




- 6. When the laser beam is on the upper (lower) part of Fig. A the up/down adjustment is made as follows:
 - (1) Insert the provided hexagon key wrench into both the upper and lower screws.






- 7. When the laser beam is in the right (left) part of Fig. B the left (right) adjustment is made as follows:
 - (1) Insert a hexagon key wrench into both the left and right screws.
 - (2) Slightly loosen the right (left) screw and tighten the left (right) screw. Make sure that the tightening tension for both screws is identical. Continue to adjust until the laser beam is aligned with the target center.



- 8. Turn the upper part of the instrument horizontally and check that the laser beam is now aligned with the target center.
- 9. Re-attach the laser plummet adjustment cap.

Note

• Tightening each of the fine adjustment screws moves the laser plummet beam in the directions shown below.




23.POWER SUPPLY SYSTEM

Operate your instrument with the following combinations of power equipment.



- When using an external battery, mount the BDC72 in place to maintain the balance of the instrument.
- Never use any combination other than those indicated below. If you do, the instrument could be damaged.

Those indicated by * are standard accessories. Others are optional accessories (sold separately) for 201, 202, and low temperature models.



Note

- Dedicated power cables differ according to the country or the area where the instrument is used. Contact your local dealer for the details.
- By using the Y cable the instrument can perform RS232C communication (D-sub 9-pin) at the same time as connecting to an external power source.

24.TARGET SYSTEM

Select a prism or a target depending on your purpose. The following are all special accessories (sold separately).



- When using a reflecting prism equipped with a target for distance and angle measurements, be sure to direct the reflective prism correctly and sight the center of the prism target accurately.
- Each reflective prism has its own prism constant value. When changing prisms, be sure to change the prism constant correction value.

Reflecting Prism System (AP Series)

Use an appropriate system for FX.

The figure on the right is an example.

Because all reflecting prisms and accessories have standardized screws, it is possible to combine these prisms, accessories, etc. according to your objectives.

Prism constant correction value: -40 mm (used alone)

Aperture : 58 mm



■ Pinpole prism (OR1PA)

Prism constant correction value: -30 mm (used alone)

: 25 mm **Aperture**



Reflective sheet target (RS series)

Prism constant correction value: 0 mm Aperture : Target size

2-point target (2RT500-K)

This target is used for two-distance offset measurement.

Prism constant correction value: 0 mm Aperture : 50 mm




Instrument height adaptor (AP41)

This device is used to adjust the height of the target.

Make sure that the instrument height "239" (mm) is displayed in the instrument height adjustment window.


Install the tribrach to the instrument height adaptor.

1. Install the tribrach to the instrument height adaptor.




2. Level the instrument and check the position of the bubble of the plate level.


3. Turn the upper part through 180° and check the bubble position. If the bubble is still centered, no adjustment is necessary. If the bubble is off-center, adjust as follows.



 ${\bf 4.} \ \ {\bf Correct\ half\ of\ the\ bubble\ displacement\ using\ levelling\ foot\ screw\ C.}$



Correct the remaining half of the displacement by using the
adjustment pin to rotate the plate level adjustment screw.
 When the plate level adjustment screw is turned in the
counterclockwise direction, the bubble moves in the same direction.



- Rotate the top of the instrument and continue adjustments until the bubble remains centered for any position of the upper part.
 If the bubble does not move to the center even when the adjustment has been repeated, ask your local dealer to adjust it.
 - Adjust the optical plummet of the AP41 instrument height adaptor following the checking and adjustment methods of optical plummet.
 "22.5 Optical Plummet"

● Base Plate (TR-101/102 series)

The circular level on the base plate for prism should be adjusted in the same way with the circular level on the main body.

T "22.1 Circular Level"

25.OPTIONAL ACCESSORIES


The following are outlines and how to use standard accessories (not all) and optional accessories.

The following items are explained in other chapters.

Power supply and target optional accessories: "23. POWER SUPPLY SYSTEM", "24. TARGET SYSTEM".

Plumb bob

The plumb bob can be used to set up and center the instrument on days when there is little wind. To use the plumb bob, unwind its cord, pass it through the cord grip piece as shown in the figure to adjust its length, then suspend it from the hook attached to the centering screw.




Tubular compass (CP7)

Slide the tubular compass into the tubular compass slot, loosen the clamp screw, then rotate the top part of the instrument until the compass needle bisects the index lines. The telescope's face 1 sighting direction in this position will indicate magnetic north. After use, tighten the clamp and remove the compass from the slot.



 The tubular compass is susceptible to the influence of nearby magnets or metal. Such influence could cause it to fail to accurately indicate magnetic north. Do not use magnetic north as indicated by this compass for base line surveying.



Telescope eyepiece lens (EL7)

Magnification: 40X Field of view: 1° 20'

Diagonal eyepiece (DE27)

The diagonal eyepiece is convenient for observations near the nadir and in narrow spaces.


Magnification: 30X

After removing the handle from the instrument loosen the attachment screw to remove the telescope eyepiece. Then screw the diagonal lens into place.

F Handle removal method: "4.1 Parts of the Instrument " Handle"



 Do not perform vertical rotation of the telescope when using the diagonal eyepiece. The diagonal eyepiece may strike the instrument causing damage.




Solar filter (OF3A)

During solar observation, attach it to the objective lens of the instrument to protect its interior and the eyes of its operator. The filter part can be flipped up without being removed.



• Do not perform vertical rotation of the telescope when using the solar filter. The solar filter may strike the instrument causing damage.



Power cable/Interface cable

Connect the instrument to a host computer using the following cables.

Cable	Notes		
DOC210	Pin number and signal level	:	RS232C compatible
EDC211 (Y cable)	D-Sub connector	:	9 pins (female)
EDC212 (Y cable)			

Note

• By using the Y cable the instrument can perform RS232C communication (D-Sub 9-pin) at the same time as connecting to an external power source.

26.SPECIFICATIONS

Except where stated, the following specifications apply to all FXs.

Telescope

Length 171mm

Aperture 45mm (EDM: 48mm)

Magnification 30X **Image Erect** Resolving power 2.5"

Field of view 1°30' (26m/1,000m)

Minimum focus 1.3m

Reticle illumination 5 brightness levels

Angle measurement

Horizontal and Vertical circles type

Detecting

FX-201/202/203: 2 sides FX-205: 1 side

Angle units Degree/Gon/Mil (selectable)

Minimum display

0.5"(0.0001gon/0.002mil)/1" (0.0002gon/0.005mil) (selectable) FX-201/202: 1" (0.0002gon/0.005mil)/5" (0.0010gon/0.020mil) (selectable) FX-203/205:

Rotary absolute encoder

Accuracy

FX-201: 1" (0.0003gon/0.005mil) 2" (0.0006gon/0.010mil) FX-202: FX-203: 3" (0.001gon/0.015mil) 5" (0.0015gon/0.025mil) FX-205:

(ISO 17123-3: 2001)

Collimation compensation ON/OFF (selectable)

Measuring mode

Horizontal angle: Right/Left (selectable)

Zenith/Horizontal/Horizontal ±90°/% (selectable) Vertical angle:

Tilt angle compensation

Type Liquid 2-axis tilt sensor

Correction unit

Range of compensation ±6' (±0.1111gon)

Automatic compensator ON (V & H/V)/OFF (selectable)

Compensation constant Can be changed

Distance measurement

Measuring method Coaxial phase-contrast measuring system

Signal source Red laser diode (690 nm) Class 3R (IEC60825-1 Ed. 3.0: 2014/FDA CDRH 21CFR Part1040.10 and

1040.11 (Complies with FDA performance standards for laser products except for deviations pursuant to Laser Notice No.56,

dated May 8, 2019.))

(When target (reflector) is set to prism or reflective sheet, the output

is equivalent to Class 1)

(Using the following reflective prism/reflective sheet target during Measuring range

normal atmospheric conditions*1/*2 is good atmospheric conditions)

Mini pole Prism-5*3: 1.3 to 500m (1,640ft) Standard prism Prism-2 X 1*3: 1.3 to 5,000m (16,400ft) (1.3 to 6,000m (19,680ft))*2

1.3 to 500m (1,640ft)

Reflective sheet RS90N-K*4: 1.3 to 300m (980ft)*5 *6

1.3 to 300m (980ft)

Reflective sheet RS50N-K*4:

1.3 to 180m (590ft)*5 *6 1.3 to 100m (320ft)

Reflective sheet RS10N-K*4: 1.3 to 60m (190ft)*5 *6 Reflectorless (White): $0.3 \text{ to } 800 \text{m} (2,620 \text{ft})^{*7}$

(0.3 to 1000m (3,280ft))*2 *8 *9

Prism (tracking)*3:

Reflective sheet target (tracking)*4:

1.3 to 1000m (3,280ft)

1.3 to 350m (1,140ft)

1.3 to 210m (680ft)*5 *6

Reflectorless (White) (tracking, road): 0.3 to 300m (980ft)*7

Minimum display

Fine/Rapid measurement: 0.0001 m (0.001 ft / 1/16 inch) / 0.001 m (0.005 ft / 1/8 inch) (selectable)

Tracking/Road measurement: 0.001 m (0.005 ft / 1/8 inch) / 0.01 m (0.01 ft / 1/2 inch) (selectable)

Maximum slope distance display

(Except for tracking)

Using prism or reflective sheet target: 9,600.000 m (31,490 ft) Reflectorless: 1,200.000 m (3,930 ft)

(Tracking)

Using prism or reflective sheet target: 1,280.000 m (4,200 ft)
Reflectorless: 768.000 m (2,520ft)
Distance unit m/ft/inch (selectable)

Accuracy (D: measurement distance; Unit: mm) (Under normal atmospheric conditions*1)

(Using prism)*3

Fine measurement: (1.5 + 2 ppm X D) mm*10 *12 *13

Rapid measurement: $(5 + 2 \text{ ppm X D}) \text{ mm}^{*12}$

(Using reflective sheet target)*4

Fine measurement: (2 + 2 ppm X D) mmRapid measurement: (5 + 2 ppm X D) mm

(Reflectorless (White))*7

Fine measurement: (2 + 2 ppm X D) mm (0.3 to 200m)*11 *12

(5 + 10 ppm X D) mm (over 200 to 350m) (10 + 10 ppm X D) mm (over 350 to 1,000m) (6 + 2 ppm X D) mm (0.3 to 200m)*11 *12

Rapid measurement: (6 + 2 ppm X D) mm (0.3 to 200m)*11 *12 (8 + 10 ppm X D) mm (over 200 to 350m)

(15 + 10 ppm X D) mm (over 350 to 1,000m)

Measurement mode Fine measurement (single/repeat/average)/Rapid measurement

(single/repeat)/Tracking/ Road (reflectorless) (selectable) (fastest time under good atmospheric conditions*2, no

compensation, EDM ALC at appropriate setting, slope distance)

Fine measurement: less than 1.5 sec + every 0.9 sec or less Rapid measurement: less than 1.3 sec + every 0.6 sec or less Tracking measurement: less than 1.3 sec + every 0.4 sec or less

Atmospheric correction

Measuring time

Temperature input range: - 35 to 60°C (in 0.1°C step)/ - 31 to 140°F (in 0.1°F step)

Pressure input range: 500 to 1,400 hPa (in 0.1hPa step) 375 to 1,050 mmHg (in 0.1mmHg step)

14.8 to 41.3 inchHg (in 0.01inchHg step)

Humidity input range: 0 to 100% (in 0.1% step)

ppm input range: -499 to 499 ppm (in 0.1 ppm step)
Prism constant correction -99 to 99 mm (in 0.1 mm step)

0mm fixed for reflectorless measurement

Earth curvature and refraction correction No/Yes K=0.142/Yes K=0.20 (selectable)

Sea level correction No/Yes (selectable)

- *1: Slight haze, visibility about 20 km, sunny periods, weak scintillation.
- *2: No haze, visibility about 40 km, overcast, no scintillation.
- *3: Face the prism toward the instrument during the measurement with the distance at 10 m or less.
- *4: Figures when the laser beam strikes within 30° of the reflective sheet target.
- *5: Measurement at -30 to -20°C (-22 to -4°F) (Low Temperature Model)/50 to 60°C (122 to 140°F) (Standard Model)
- *6: The temperature of the lower limit is -30°C (-22°F) when using reflective sheet target. (Low Temperature Model)

- *7: Figures when using Kodak Gray Card White side (reflection factor 90%), brightness level is less than 5,000 lx and the laser beam strikes orthogonally the White side.
- *8: Figures when using Kodak Gray Card White side (reflection factor 90%), brightness level is less than 500 lx and the laser beam strikes orthogonally the White side. (800 m or more)
- *7,*8:When performing reflectorless measurement, the possible measurement range and precision will change depending on the target reflection factor, weather conditions and location conditions.
- *9: Figures may differ according to the country or the area.
- *10: Accuracy is (2 + 2 ppm X D) mm for distance range 1.3 to 2 m.
- *11: Accuracy is (5 + 2 ppm X D) mm for distance range 0.3 to 0.66 m or less.
- *12: Figures are 4 ppm instead of 2 ppm at -35 to -30°C (-31 to -22°F).
- *13: ISO 17123-4: 2012

Guide Light

Light source LED (red 626 nm/green 524 nm)

Distance 1.3 to 150 m*1

Visible range Right and Left/Upward and Downward: ± 4° (7 m/100 m)

Resolving power at center area (width) 4' (about 0.12 m/100 m)
Brightness 3 levels (bright/normal/dim)

Internal memory

Capacity 1 GB (includes memory for program files)

External memory

USB flash drive

Data transfer

Data input/output Asynchoronous serial, RS232C compatible

USB Ver. 2.0, Host (Type A) and Client (Type miniB)

Bluetooth wireless communication*14

Transmission method FHSS Modulation GFSK

Frequency band 2.402 to 2.48GHz

Bluetooth profile SPP
Power class Class 1

Usable range about 10 m (while in communication with SHC500)*15 *16

- *14: Bluetooth function may not be built in depending on telecommunications regulations of the country or the area where the instrument is purchased. Contact your local dealer for the details.
- *15: No obstacles, few vehicles or sources of radio emissions/interference in the near vicinity of the instrument, no rain.
- *16: Usage range could be shorter depending on specifications of Bluetooth device to communicate.

Power Supply

Power source Rechargeable Li-ion battery BDC72

Working duration at 20 °C

Distance measurement (Fine distance measurement (single) repeated every 30 sec)

BDC72: about 20 hours BT-73QB (external battery, optional accessory):

about 49 hours

Battery state indicator 4 levels

Auto power-off 5 levels (5/10/15/30 min/Not set) (selectable)

External power source 6.7 to 12V

Battery (BDC72)

Nominal voltage: 7.2V Capacity: 5,986mAh

Dimensions: 40 (W) x 70 (D) x 40 (H) mm

Weight: about 220g

Charger (CDC77)

Input voltage: 100 to 240VAC

Charging time (at 25°C, when two batteries are charged at the same time):

BDC72: about 8 hours

(Charging can take longer than the times stated above when

temperatures are either especially high or low.)

Charging temperature range: 0 to 40°C Storage temperature range: -20 to 65°C

Size: 94 (W) X 102 (D) X 36 (H) mm

Weight: about 250g

General

Operating system Windows Embedded Compact 7

Display

3.5 inch Transmissive TFT QVGA color LCD
Backlight:
LED: 9 brightness levels (0 to 8) (selectable)

Touch panel: Resistance-sensitive analog type

Keyboard 29 keys Key backlight: Yes

Trigger key Yes (right side)

Sensitivity of levels

Circular level: 10'/2 mm Plate level (Low temperature model only): 30"/2 mm

30 /

Electronic Circular levels:

Graphic display range: 6' (inner circle)

Digital display range: ±6' 30"

Optical plummet

Image:ErectMagnification:3XMinimum focus:0.3 m

Laser plummet*17

Signal source: Red laser diode 635 ±10nm (Class 2 IEC60825-1 Ed. 3.0:2014/FDA

CDRH 21CFR Part 1040.10 and 1040.11 (Complies with FDA performance standards for laser products except for deviations

pursuant to Laser Notice No.56, dated May 8, 2019.))

Beam accuracy: 1mm or less (when tripod head height is 1.3m).

Spot diameter: ø3mm or less Brightness control: 5 levels

Auto power-off: Provided (power cut off after 5 minutes)

Calendar/clock function Yes

Laser-pointer function ON/OFF (selectable)

Operating temperature

Standard models:

Low temperature models:

Storage temperature range

-20 to 60 °C (-4 to 140 °F) (no condensation) *18

-30 to 50 °C (-22 to 122 °F) (no condensation)

-30 to 70°C (-22 to 158 °F) (no condensation)

Dust and water resistance IP65 (IEC 60529:2001)

Instrument height: 192.5 mm from tribrach mounting surface 236mm +5/-3mm from tribrach bottom

Size (with handle)

Display on one side: 191 (W) X 174 (D) X 348 (H) mm Display on both sides: 191 (W) X 190 (D) X 348 (H) mm

Weight (with battery and tribrach) 5.7kg (12.3 lb)

*17: Laser plummet is available as a factory option depending on the country or the area where the instrument is purchased.

*18: No direct sunlight for using high temperatures of 50 to 60°C (122 to 140°F).

27.1 Manually Indexing the Vertical Circle by Face 1/2 Measurement

The 0 index of the vertical circle of your instrument is almost 100% accurate, but when it is necessary to perform particularly high precision vertical angle measurements, you can eliminate any inaccuracy of the 0 index as follows.




• If the power is cut off, the vertical circle indexing is ineffective. Do it again every time the power is turned on.

PROCEDURE

 Select "Instrument" in <Inst. config.>. Set "V manual" (vertical circle indexing method) to "Yes".
 "20.1 Observation Conditions"

<V manual 0 set> is displayed.




- 2. Carefully level the instrument.
- 3. Accurately sight a clear target with a distance of 30 m or more in the horizontal direction with the telescope in Face 1.

Press **[OK]**. The vertical angle V2 is displayed under "Take F2".

4. Turn the upper part through 180° and clamp it. Then set the telescope in the Face 2 position and accurately sight the same target.

Press [OK].

The vertical and horizontal angles are displayed. This concludes the vertical circle indexing procedure.



27.2 Correction for Refraction and Earth Curvature

The instrument measures distance, taking into account correction for refraction and earth curvature.


Distance Calculation Formula

Distance Calculation Formula; with correction for refraction and earth curvature taken into account. Follow the Formula below for converting horizontal and vertical distances.

Horizontal distance D = AC(α) Vertical distance Z = BC(α) D = L{cos α - (2 θ - γ) sin α } Z = L{sin α + (θ - γ) cos α }

 $\theta = L \cdot \cos \alpha/2R$: Earth curvature correcting item $\gamma = K \cdot L\cos \alpha/2R$: Atmospheric refraction correcting item K = 0.142 or 0.2 : Coefficient of refraction (Ref.index)

 $\begin{array}{lll} \mbox{R = 6371km} & : & \mbox{Radius of earth} \\ \mbox{α} & : & \mbox{Altitude angle} \\ \mbox{L} & : & \mbox{Slope distance} \end{array}$



Changing Coefficient of refraction value K (Ref.index): "20.1 Observation Conditions"

Region/ Country	Directives/ Regulations	Description
U.S.A.	Regulations FCC-Class B	FCC Compliance WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: - Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. - Consult the dealer or an experienced radio / TV technician for help. Means of conformity This device complies with part 15 of the FCC Rules, Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter. This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines. This equipment has very low levels of RF energy that is deemed to comply without maximum permissive exposure evaluation
0 111	- i:	(MPE). But it is desirable that it should be installed and operated keeping the radiator at least 20cm or more away from person's body.
California, U.S.A	Proposition 65	★ WARNING: This product can expose you to chemicals including Lead, which is known to the State of California to cause birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.
California, U.S.A	Perchlorate Material (CR Lithium Battery)	This product contains a CR Lithium Battery which contains Perchlorate Material-special handling may apply. See http://www.dtsc.ca.gov/hazardouswaste/perchlorate/ Note; This is applicable to California, U.S.A. only

Region/ Country	Directives/ Regulations	Description	
California and NY, U.S.A.	Recycling Batteries	DON'T THROW AWAY RECHARGEABLE BATTERIES, RECYCLE THEM. Topcon Positioning Systems Inc., United States Return Process for UsedRechargeable Nickel Metal Hydride, Nickel Cadmium, Small Sealed Lead Acid, and Lithium Ion, Batteries In the United States Topcon Positioning Systems Inc., has established a process by which Topcon customers may return used rechargeable Nickel Metal Hydride(Ni-MH), Nickel Cadmium(Ni-Cd), Small Sealed Lead Acid(Pb), and Lithium Ion(Li-ion) batteries to Topcon for proper recycling and disposal. Only Topcon batteries will be accepted in this process. Proper shipping requires that batteries or battery packs must be intact and show no signs of leaking. The metal terminals on the individual batteries must be covered with tape to prevent short circuiting and heat buildup or batteries can be placed in individual plastic bag. Battery packs should not be dissembled prior to return. Topcon customers are responsible for complying with all federal, state, and local regulations pertaining to packing, labeling, and shipping of batteries. Packages must include a completed return address, be prepaid by the shipper, and travel by surface mode. Under no circumstance should used/recyclable batteries by shipped by air. Failure to comply with the above requirements will result in the rejection of the package at the shipper's expense. Please remit packages to: Topcon Positioning Systems, Inc. C/O Battery Return Dept. 150 7400 National Dr. Livermore, CA 94551 DON'T THROW AWAY RECHARGEABLE BATTERIES, RECYCLE THEM.	
Canada	ICES-Class B	This class B digital apparatus meets all requirements of Canadian interference-Causing Equipment Regulations. Cet appareil numérique de la class B respecte toutes les exigences du Réglement sur le matérique brouilleur du Canada. This Class B digital apparatus complies with Canadian ICES-003 Cet appareil numerique de la Class B est conforme a la norme NMB-003 du Canada. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of this device. This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment and meets the RSS-102 of the IC radio frequency (RF) Exposure Guidelines. This equipment has very low levels of RF energy that is deemed to comply without maximum permissive exposure evaluation (MPE). But it is desirable that it should be installed and operated keeping the radiator at least 20cm or more away from person's body.	

Region/ Country	Directives/ Regulations	Description		
EU	EMC-Class B RE	EMC NOTICE In industrial locations or in proximity to industrial power installations, this instrument might be affected by electromagnetic noise. Under such conditions, please test the instrument performance before use.		
		This product complies with the electromagnetic environmental testing of industrial locations.		
		Hereby, TOPCON CORPORATION declares that the radio equipment type of this product is in compliance with Directive 2014/53/EU.		
		EU declaration of conformity is available depending on your request. Contact your local dealer.		
		Manufacturer Name: TOPCON CORPORATION Address: 75-1, Hasunuma-cho, Itabashi-ku, Tokyo, 174-8580 JAPAN		
		Europe Representative and Importer Name: Topcon Europe Positioning B.V. Address: Essebaan 11, 2908 LJ Capelle a/d IJssel, The Netherlands		
EU	WEEE Directive	WEEE Directive This symbol is applicable to EU members states only. Following information is only for EU-member states: The use of the symbol indicates that this product may not be treated as household waste. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. For more detailed information about the take-back and recycling of this product, please contact your supplier where you purchased the product or consult.		
EU	EU Battery Directive	EU Battery Directive This symbol is applicable to EU members states only. Battery users must not dispose of batteries as unsorted general waste, but treat properly. If a chemical symbol is printed beneath the symbol shown above, this chemical symbol means that the battery or accumulator contains a heavy metal at a certain concentration. This will be indicated as follows: Hg: mercury(0.0005%), Cd: cadmium(0.002%), Pb: lead(0.004%) These ingredients may be seriously hazardous to human and the global environment. This product contains a coin cell. You cannot replace batteries by yourself. When you need to replace and/or dispose batteries, contact your local dealer.		

29.INDEX

Α		
	Ack mode	
	Adjusting backlight brightness/turning the reticle illumination and key backlight ON/OFF	
	Atmospheric correction factor	
_	Automatic tilt angle compensation mechanism	87
В		
_	Bluetooth device address	38
С		
	Cold boot	
	Collimation correction	87
D		
	Date and Time	
	Dist.reso. (Distance resolution)	88
Ε		
	EDM ALC	89
	Eliminating parallax	42
G		
	Guide light	10
Н		
	H dist	87
	Horizontal angle settings54	, 59
I		
	Inch (Fraction of an inch)	101
	Instrument height mark	g
Κ		
	Key backlight	90
L		
	Laser-pointer function	10
	Laser-pointer off	
Р	· ·	
-	Power-saving automatic cut-off/Backlight Off	89
	Precaution when performing resection	
	Prism constant correction90	
	Problems Powering OFF	36
R	· · · · · · · · · · · · · · · · · · ·	
	Resection calculation process	63
	Resume function	
S		
_	Sea level correction	87
	Sighting collimator	
	Slope area	
Т	'	
-	Terminate	37
	Tracking reso. (Trackign resolution)	88
	Trigger key	
V		•
-	V mode (vertical angle display method)	87

TOPCON CORPORATION (Manufacturer)

75-1 Hasunuma-cho, Itabashi-ku, Tokyo 174-8580, Japan https://www.topcon.co.jp
Please see the following website for contact addresses.

GLOBAL GATEWAY https://global.topcon.com

©2020 TOPCON CORPORATION ALL RIGHTS RESERVED